

Basic Type 7 inch Color LCD Logic Panel

Features

- Supports cost reducing, space saving, easy control by PLC+HMI+I/O module integration
- Adopts 7 inch wide TFT LCD for realizing True Color with 16,777,216 colors
- Analog touch method
 - : Free tag arrangement than matrix touch method
- Supports basic I/O of input 16-point, output 16-point
- Supports several device
 - (auxiliary device 10K Word, data device 10K Word, etc)
- Built-in large capacity memory
 (program memory: 2 000 step)
 - (program memory: 8,000 step, drawing memory: 16MB)
- Built-in position control function
 - : Provides simultaneous output for max. 100kHz pulse 2-point
- Easy software upgrade available on website
 - (1) LP firmware file
- (2) GP Editor (drawing program)
- (3) atLogic (logic program) (4) Additional protocol
- (5) Language and font, etc
- Data logger function
 - : Supports data gathering and backup of controller
- Supports variable image library
- Enables to monitor multi stations and multi channels at the same time
- Supports several interface
 - : Easy to connect various external devices with RS232C 2 ports and RS232C/RS422 multi communication ports
 - : Enables to extend additional external I/O (when connecting Autonics ARM Series, one communication cable enables to extend 64-point per address, up to 31 address)



- Supports several fonts: Supports window true type and several bitmap font (selectable)
- Device monitoring function: Enables to monitor/control variable of connected control through communication port
- Printer/Barcode reader connection: Enables to print out alarm history, to read barcode



Manual

For the detail information and instructions, please refer to user manual and user manual for communication, and be sure to follow cautions written in the technical descriptions (catalog, website). Visit our website (www.autonics.com) to download manuals.


• GP Editor user manual

It describes how to write screen data, and is about related usage of LP-S070 HMI function.

- atLogic user manual, atLogic programming manual, LP Series command manual It contains install method and usage, commands, etc of atLogic.
- GP/LP user manual for communication: It describes connection for external devices such as PLC.
- LP-S070 user manual: It describes general information of the installation and usage of LP-S070 and system Contents.

Ordering Information

Model	Item	Series	Monitor size	Display unit	Color	Power supply	Interface	Module	I/O composition	I/O connector
LP-S070-T9D6-C5T			TFT Color LCD	Color	r 16,777,216 color	24VDC=	RS232C, RS422, USB HOST USB DEVICE, Ethernet All-in-		Terminal block connector	
LP-S070-T9D6-C5R	Logic	S series						All-in- one	OUT:	Ribbon cable connector
LP-S070-T9D7-C5T	panel	5 series 7					RS232C (2), USB HOST			Terminal block connector
LP-S070-T9D7-C5R							USB DEVICE, Ethernet			Ribbon cable connector



V-58 Autonics

Basic Type 7 inch Color Logic Panel

Specifications

Model		LP-S070-T9D6-C5T	LP-S070-T9D6-C5R	LP-S070-T9D7-C5T	LP-S070-T9D7-C5R			
I/O co	nnector type	Terminal block connector	Ribbon cable connector	Terminal block connector	Ribbon cable connector			
Power	r supply	24VDC==						
Allowa	able voltage range	90 to 110% of power supp	ly					
Power	r consumption	Max. 7.2W						
	LCD type	7 inch TFT Color LCD						
ing	Resolution	300×480 dots						
Graphic drawing performance	Display area	152.4×91.44mm						
C d	Color	16,777,216 color						
aphic drawir performance	LCD view angle	Within each 60°/ 45°/ 60°/ 60° of top/bottom/left/right						
9 9	Backlight	White LED						
_	Brightness	Adjustable by software						
<u>ق</u>	Language ^{×1}	English, Korean						
Graphic drawing performance	Text	Vector font						
ic Fi	Graphic drawing memory	16MB						
per per	Number of user screen	500 pages						
<u>ق</u> _ ا	Touch switch	Analog touch						
	Command	Basic command: 28, appli	sasic command: 28, application command: 233					
o l	Program capacity	8K step						
auc a	Processing time	Average: approx. 2μs/bas	ic command, application co	ommand				
Control	I/O control type	Batch processing						
5 음 [Computer control mode	Repeated-doubling method, interrupt processing						
مَ	Device range	Refer to 'LP-S070 user ma	Refer to 'LP-S070 user manual'					
l	Special function ^{×2}	Positioning function						
Carial	interface	Asynchronous method: ea	ch port of RS232C, RS422					
Seliai	Interrace	Each port of RS232C, RS4	122	Two ports of RS232C				
JSB i	nterface	Each of USB Host, USB D	Device (Version 1.1)					
Etherr	net interface	IEEE802.3 (U), 10/100Bas	se-T					
Real-t	ime controller	RTC embedded						
Batter	y life cycle	Approx. 3 years at 25°C						
nsula	tion resistance	Over 100MΩ (at 500VDC	megger)					
Groun	nd	3rd grounding (max. 100Ω	2)					
Noise	immunity	±0.5kV the squre wave no	ise (pulse width: 1μs) by th	ne noise simulator				
Withst	tanding voltage	500VAC 50/60Hz for 1 min						
Vibra	Mechanical	· · ·		min) in each X, Y, Z directio				
tion	Malfunction	· · · · · · · · · · · · · · · · · · ·		nin) in each X, Y, Z direction	for 10 min			
Shock	Mechanical	` ' ' ' ' '	each X, Y, Z direction for 3					
J. 100K	Malfunction		each X, Y, Z direction for 3	times				
Enviro	Ambient temperature	emperature 0 to 50°C, storage: -20 to 60°C						
ment	Ambient humidity	35 to 85%RH, storage: 35 to 85%RH						
Protec	rotection structure IP65 (front panel, IEC standard)							
Accessory Fixing bracket: 4, battery (included)								
Appro	val	CE						
Weigh	nt×3	Approx. 699g (approx. 51	Og)					

X1: Supported language can be added.

Input/Output Performance

Input performance		Output performance	
Input point	16-point	Output point	16-point
Insulation method	Photo coupler insulation	Insulation method	Photo coupler insulation
Voltage range	19.2 to 28.8VDC==	Voltage range	19.2 to 28.8VDC==
Rated input voltage	24VDC	Rated input voltage	24VDC==
Input resistance	Contact X0 to X5: approx. 10mA Contact X6 to XF: approx. 4mA	Max. load current	0.1A/1point, 1.6A/1COM
Input resistance	Contact X0 to X5: 2.2kΩ, Contact X6 to XF: 5.6kΩ	Max. voltage falling when ON	Max. 0.2VDC==
Response time	1ms	Response time	1ms
Common method	16-point/1COM	Common method	16-point/1COM
Acceptable wire	0.3 to 0.7mm ²	Acceptable wire	0.3 to 0.7mm ²

CONTROLLERS

MOTION DEVICES

SOFTWARE

(J) Temperature Controllers

(L) Power Controllers

(O) Digital Panel Meters

(R) Digital Display Units

(T) Switching Mode Power Supplies

(U) Recorders

(V) HMIs

(W) Panel PC

(X) Field Network Devices

Autonics V-59

X2: Please refer to 'LP-S070 user manual' for more special function.

^{*3:}The weight includes packaging. The weight in parenthesis is for unit only. *Environment resistance is rated at no freezing or condensation.

■ Function


Line, rectangle, circle, text, bitmap					
Displays the designated device as numerical value. (decimal, hexadecimal, octal, binary, real number)					
Displays the designated device value as ASCII character.					
Displays current time or date.					
Registers alarm history.					
Displays generated (not backed up) alarm.					
Displays the designated comment as device status or value.					
Displays lamp as device status.					
Displays the designated parts as device status and value.					
Displays several device values with a graph of broken line.					
Displays change of device value for time with a graph of broken line.					
Displays a device value with a bar graph.					
Displays a ratio of several device values with pie graph.					
Displays a device value as panel meter.					
Screen is switched, word/bit device values are set when it touched.					
Configures user input value in device.					
Configures user input ASCII code value in device.					
Monitors/Controls LP operation from PLC.					
Reads/Writes several PLC device collectively.					
Only acceptable user can observe/operate important data.					
Connects barcode reader, read barcode.					
Warning message is floated when alarm is generated.					
Specific bit device is ON/OFF for designated day and time.					
Available to form dynamically overlapping another base screen on the base one.					

Dimensions (unit: mm) • Panel cut-out Min. 240 185 Max. 4-R3 186^{+1.1} 126+10 175 . E ※Panel thickness : max. 4mm 6.5 28.5 194 • Fixing bracket M4 BOLT 125

V-60 Autonics

Basic Type 7 inch Color Logic Panel


Unit Description




- Ethernet port: For connecting LAN cable and hub, use direct cable, and for connecting PC directly, use cross cable.
- USB Device: When setting USB Device mode to HID mode in serial setting, it is for uploading/downloading GP Editor, atLogic project. When setting to Storage mode, it is for transferring/coping data between PC and LP-S070 with recognition as a storage device by PC.
 For details, please refer to 'LP-S070 user manual'.
- USB Host: It is for transferring/coping data between USB storage device and LP-S070 and upgrading firmware.
- RS232C, RS422 port: For more information, refer to '■ Serial Interface' of GP/LP Common Features.

Installation

- 1. Set LP-S070 in panel.
- 2. Set fixing brackets in 4 slots (2 slots is in upper side, 2 slots is in lower side).



3. Tighten fixing bracket with M4 screw driver and tightening torque is 0.3 to 0.5N·m.



SENSORS

CONTROLLERS

MOTION DEVICES

SOFTWARE

(J) Temperature Controllers

(K) SSRs

(L) Power Controllers

Counters

(N) Timers

(O) Digital Panel Meters

(P) Indicators

(Q) Converters

(R) Digital Display Units

(S) Sensor Controllers

(T) Switching Mode Power Supplies

(U) Recorders

(V) HMIs

(W) Panel PC


(X) Field Network

Autonics V-61


■ Input/Output Wiring

© LP-S070-T9D6 (7)-C5R

• Input wiring (source type input module)




• Output wiring (sink type output module)




© LP-S070-T9D6 (7)-C5T

• Input wiring (source type input module)



• Output wiring (sink type output module)



XCheck the pin number of the case before wiring.

■ Sold Separately

O Connector socket

Please contact to the manufacturer of the socket and cable.

	Standard product	Manufacturer
Socket	HIF3BA-20D-2.54R	Hirose Electric

O I/O terminal block and I/O cable

Suitable I/O terminal block	INPUT/OUTPUT	Suitable I/O cable
AFS-H20	INPUT	— CH20-HP□-4R
(Interface terminal block)	OUTPUT	UU20-UL-4K
ABS-H16PA (TN)-NN (Relay terminal block)	OUTPUT	CH20-HP□-C1T1R
AFE4-H20-16LF	INPUT	CH20-HP□-C1T5R
(Sensor connector terminal block)	OUTPUT	CH20-HP□-C1T1R
		CO20-HP□-R (open type cable)
	_	CO20-HP⊡-L (open type cable)

XIt is only for ribbon cable connector (hirose connector) type.

© Communication cable (RS232C, RS422 port)

Serial connection cables which connect GP/LP with PLC or other external devices are sold separately. Refer to "GP/LP Communication Cables".

V-62 Autonics

X"□" is cable length. (Basic specification 010: 1m, 020: 2m, the others are option)

XFor more information, refer to "I/O terminal block & cable catalog".

Basic Type 7 inch Color Logic Panel

Serial Interface

- All devices are connectable with LP-S070 including PC, PLC, serial printer, barcode reader and dedicated connectors can be connected with both RS232C and RS422 ports.
- Use the dedicated communication cable for the each connected device. (Refer to the "GP/LP Communication Cables")
- For the method of wiring external devices like PLC, refer to "GP/LP communication manual".

Port	NO.	Pin
RS232C	1	Not used
5	2	RXD
5 0 9	3	TXD
4 8	4	DTR
3 • 7	5	SG
2 6	6	DSR
1 • • •	7	Not used
D-Sub 9-pin	8	Not used
Male	9	Not used
RS422	1	TXD+
5 (0	2	RXD+
4 0 0 6	3	Not used
0 7	4	Not used
_ 0 8	5	SG
1 019	6	TXD-
1 6 0 0	7	RXD-
D-Sub 9-pin 8		Not used
Female	9	Not used

Power Wiring

- For power supply, use the wire of which cross section is at least 0.75mm² and use the wire of which cross section is at least 1.25mm² for grounding.
- Use round terminal with at least 3mm of internal diameter and less than 6mm of external diameter.
- Do not apply power before power line connection.
- · Check power polarity.
- Tighten the terminal screw with 0.5 to 0.8N·m torque.
- Ground resistance should be less than 100Ω and ground it separately.

FG 24VDC

Battery Replacement

Please contact out distributor to replace battery.

It may cause an explosion or a fire when improper battery is used.

Cautions during Use

- 1. Follow instructions in 'Cautions during Use'. Otherwise, it may cause unexpected accidents.
- 2. 24VDC power supply should be insulated and limited voltage/current or Class 2, SELV power supply device.
- 3. Install a power switch or circuit breaker in the easily accessible place for supplying or disconnecting the power.
- 4. Operate the product after supplying power to the product, input/output equipment, and load. If operate product before supplying power, it may result in output error or malfunction.
- 5. Keep away from high voltage lines or power lines to prevent inductive noise. Do not use near the equipment which generates strong magnetic force or high frequency noise.
- 6. Make a required space around the unit for radiation of heat, and do not block ventilation openings.
- 7. Do not push the touch panel with a hard and sharp object or push the panel with excessive force. It may result in fire or malfunction.
- 8. When skin is smeared with liquid crystal from the broken LCD, rinse with running water for over 15 minutes. If it gets into the eyes, rinse eyes with running water for over 15 minutes and contact a doctor.
- 9. This unit may be used in the following environments.
 - (Indoors (in the environment condition rated in 'Specifications')
 - ②Altitude max. 2,000m
 - 3 Pollution degree 2
 - 4 Installation category II

SENSORS

CONTROLLERS

MOTION DEVICES

SOFTWARE

(J) Temperature Controllers

Power Controllers

Digital Panel Meters

(P) Indicators

(Q) Converters

(R) Digital Display Units

(S) Sensor Controllers

(T) Switching Supplies

(U) Recorders

(V) HMIs

(X) Field Network

V-63 **Autonics**