

## Stepping Motor and Driver Package $\alpha_{STEP}$

### High-Efficiency AR Series DC Power-Supply Input

 Built-in Controller Type

Pulse Input Type

The extensive AR Series DC Power-Supply Input lineup that utilizes high-efficiency technology.

Two types are available: the built-in controller type equipped with interfaces that connect to a wide variety of host systems and the pulse input type that enables the motor to be controlled from a pulse generator provided by the customer.



# Built-in Controller Drivers Support FLEX, a Feature That Enables You to Select the Control Method in Accordance with Your Operation System.

## FLEX

### What is FLEX?

FLEX is a general name for products that support FA network control via I/O control, Modbus (RTU) control, and network converters.


It makes connections and controls easy and reduces the total lead time for building systems.



## Our Unique Closed Loop Control Providing High Reliability

### Continues Operation Even During Abrupt Load Changes and Accelerations

During normal operation, the motor operates synchronously with command pulses in open loop mode. When an overload condition is detected, the motor instantly switches to closed loop mode to correct the rotor position.



#### Normal (Positioning deviation is less than ±1.8°)


Motor runs in open loop mode like a stepping motor.

#### Overload Condition (Positioning deviation is ±1.8° or more)

The closed loop mode is engaged to maintain the positioning operation.

### Rotor Position Detection Sensor (Resolver)

- The sensor is compact and slim, making the overall length of the motor shorter.
- When compared with typical optical encoders, this sensor is superior in heat resistance, vibration resistance, etc.
- As encoder cables are not needed, only a single cable is needed for the connection between the motor and driver.



Rotor Position Detection Sensor

### Alarm Signal Output in Case of Abnormality

If an overload is applied continuously, an alarm signal is output. When the positioning is complete, an END signal is output. This ensures the same level of reliability achieved by a servo motor.

### Also Supports Absolute Systems

You can build an absolute system that detects absolute positions by connecting the accessory battery (sold separately). (available only on the built-in controller type)



Battery Set (Sold separately)


## Stepping Motor Advantages

### Excellent Synchronicity and High Response Operation

#### ◇Frequent Starting and Stopping

Since they operate synchronously with pulse commands and generate high torque with a compact body, stepping motors offer excellent acceleration performance and response.


They are ideal for applications requiring frequent starting and stopping.



Measurement Condition: Feed 1/5 rotation  
Inertial Load:  $250 \times 10^{-7} \text{ kg}\cdot\text{m}^2(\text{J})$


### No Tuning

Positioning is still possible without gain tuning even when the load fluctuates due to use of a belt mechanism, cam or chain drive, etc.



### Holding the Stop Position

During positioning, the motor stops with its own holding torque without hunting. Accordingly, stepping motors are ideal for applications where the low rigidity of the mechanism requires absence of vibration upon stop.



Features

Lineup

System Configuration

Product Line

Specifications and Characteristics

Dimension

Connection and Operation

Combination List

Extended Functions

How to Read Specifications and Characteristics


Accessory

Controller





## Connects to a Wide Variety of Host Systems

Built-in Controller Type  
Pulse Input Type

### Select the Control Method in Accordance with Your Operation System



### Representative Systems



The following products are available for setting data on built-in controller drivers.

**Control Module OPX-2A**  
(sold separately)  
(→ Page 53)



**Data Setting Software MEXE02**  
(→ Page 54)



or

You can use these to set drivers' internal parameters and set and change data. You can also use these to set speeds, monitor the I/O, and perform teaching.

# Highly Functional, Compact Driver

Features

Lineup

System Configuration

Product Line

Characteristics and Specifications

Dimension

Connection and Operation

Combination List

Extended Functions

How to Read Specifications and Characteristics

Accessory

Controller

## Compact DC Power-Supply Input Driver


The compact DC power input driver makes it possible to reduce the space needed for installing control boxes and devices. The driver can be mounted directly to a DIN rail, so no screws are necessary.



## 48 VDC Compatible

The motor runs on a 24 VDC or 48 VDC power supply. Choose the power supply that you have available. The torque is higher when 48 VDC is used rather than 24 VDC. (□28 only accepts 24 VDC input.)

### AR66SAK-◇




## Push-Motion Operation

A force is continuously applied to the load. When contact is made with the load, the motor switches to push-motion operation and applies constant torque to the load.

**Note**

- Push-motion operation requires a data module **OPX-2A** (sold separately) or data setting software **MEXEO2**.
- Do not perform push-motion operation using geared motors. Doing so may damage the motor or gearhead.




Continuous Operation is Achieved Due to the Reduction of Motor Heat Generation by Utilizing High-Efficiency Technology.

## Lower Heat Generation


Significant reduction in heat generation has been achieved through high-efficiency technology.

Temperature Distribution by Thermography



Comparison under the Same Conditions.


Motor Case Temperature under Same Operating Conditions



## Energy Savings

The power consumption is 30% less than a conventional model (also by Oriental Motor).

Power Consumption




CO<sub>2</sub> emission: 30% less\* than a conventional model (also by Oriental Motor)

\*Assuming operation at a duty of 40%

## Continuous Operation (Operation at high frequency)

The AR Series can be operated at high frequency.

You can drive the motor continuously.



**Note**

When the motor is operated continuously, a heat sink of a capacity at least equivalent to an aluminum plate with a size of 100×100 mm, 6 mm thick is required.

## Motor Lineup

### Types and Features of Standard and Geared Motors

	Type	Feature	Gear Ratio	Permissible Torque and Maximum Torque[N·m]	Backlash [min]	Basic Resolution [°/Pulse]	Output Shaft Rotation Speed[r/min]
Standard Type		● AR Series standard model	—	Max. Holding Torque 2	—	0.36	4000
Low Backlash	TH Geared Type (Spur gear mechanism)	● High speed (Low gear ratio)  (A wide variety of gear ratios for selecting the desired step angle (Resolution))	1:3.6, 1:7.2, 1:10, 1:20, 1:30	12	45	0.012	500
	PS Geared Type (Planetary gear mechanism)	● High speed (Low gear ratio) ● High permissible torque ● High maximum torque ● Center shaft	1:5, 1:7.2, 1:10, 1:25, 1:36, 1:50 (A wide variety of gear ratios for selecting the desired step angle (Resolution))	Permissible Torque 37 Maximum Torque 60	35	0.0072	600
Non-Backlash	PN Geared Type (Planetary gear mechanism)	● High speed (Low gear ratio) ● High positioning accuracy ● High permissible torque ● High maximum torque ● Center shaft	1:5, 1:7.2, 1:10, 1:25, 1:36, 1:50 (A wide variety of gear ratios for selecting the desired step angle (Resolution))	Permissible Torque 37 Maximum Torque 60	3	0.0072	600
	Harmonic Geared Type (Harmonic drive)	● High resolution (High gear ratio) ● High positioning accuracy ● High permissible torque ● High maximum torque ● Center shaft	1:50, 1:100	Permissible Torque 37 Maximum Torque 55	0	0.0036	70

#### Note

The values shown above must be used as reference. These values vary depending on the motor frame size and gear ratio.

### Frame Sizes

Four motor frame sizes are available for the built-in controller type and for the pulse input type.  
(□42 : indicates a motor frame size of 42 mm)

Motor Type		<input type="checkbox"/> 28 ( <input type="checkbox"/> 30*1)	<input type="checkbox"/> 42	<input type="checkbox"/> 60	<input type="checkbox"/> 85 ( <input type="checkbox"/> 90*2)
Standard Type	Without Electromagnetic Brake	●	●	●	●
	Electromagnetic Brake Type		●	●	●
TH, PS, PN, Harmonic Geared Type	Without Electromagnetic Brake	●	●	●	●
	Electromagnetic Brake Type		●	●	●

\*1 Harmonic geared type

\*2 Geared type

### Conformance to Various Directives

#### ◇CE Marking

This product has CE Marking affixed under the EMC Directive and Low Voltage Directive.

Product	CE Marking
Motor	Low Voltage Directive
Driver	EMC Directive

● The EMC value changes according to the wiring and layout. Therefore, the final level must be checked with the product incorporated in the user's equipment.

Features

Lineup

System Configuration

Product Line

Specifications and Characteristics

Dimension

Connection and Operation

Combination List

Extended Functions

How to Read Specifications and Characteristics

Accessory

Controller

## System Configuration

### Built-in Controller Type - Standard Type with Electromagnetic Brake

An example of system configuration with I/O control or RS-485 communication is shown below.

\*1 Not supplied.

\*2 Required for I/O control drive.

Features

Lineup

System Configuration

Product Line

Specifications and Characteristics

Dimension

Connection and Operation


Combination List

Extended Functions

How to Read Specifications and Characteristics

Accessory

Controller



### System Configuration Example

AR Series	+	Sold Separately	
AR66SMKD-3		Motor Installation Bracket PAL2P-5	Flexible Coupling MCV251010

The system configuration shown above is an example. Other combinations are available.

## ● Pulse Input Type - Standard Type with Electromagnetic Brake

An example of a single-axis system configuration with the **PG1200** controller is shown below.

\*Not supplied.

### Accessory (Sold separately)

#### Vibration Reduced When Used in Combination



**MCV Coupling**  
([Page 60](#))

#### Cable Used for Evaluations Related to EMC Directives

When extending the distance between the motor and driver without using the included cable



or



(For electromagnetic brake)  
Connection Cable Sets  
Flexible Connection Cable Sets  
([Page 55](#))

(For electromagnetic brake)  
Extension Cable Sets  
Flexible Extension Cable Sets  
([Page 55](#))

### Accessory (Sold separately)

Control Module

([Page 53](#))

Communication Cable  
for the Data Setting  
Software

([Page 54](#))




or



Data Setting Software

**MEXEO2**

([Page 54](#))



To a USB port

Computer\*

### AR Series

**Motor**



For Electromagnetic  
Brake  
24 VDC Power Supply\*

For Motor

The product comes with a 1 m, 2 m or 3 m  
cable (for motor and electromagnetic brake).

**Driver**



### Controller (Sold separately)



Controller  
([Page 63](#))

**Programmable  
Controller\***

**24 VDC Power  
Supply\***

**DC Power Supply\***  
(Main power supply)

### Accessory (Sold separately)



**Motor Installation Bracket**  
([Page 63](#))



**General-Purpose Cable**  
([Page 58](#))



**Connector - Terminal Block  
Conversion Unit**  
([Page 58](#))

● User's manual that explains how to use these products are available. For details, please contact the nearest Oriental Motor sales office, or download the manuals from the Oriental Motor website. <http://www.orientalmotor.com.sg/>

## ● System Configuration Example

<b>AR Series</b>	+	<b>Sold Separately</b>			
		Controller	Motor Installation Bracket	Flexible Coupling	Connector – Terminal Block Conversion Unit (1 m)
<b>AR66SMK-3</b>		<b>PG1200</b>	<b>PAL2P-5</b>	<b>MCV251010</b>	<b>CC36T1</b>

● The system configuration shown above is an example. Other combinations are available.

## Product Number Code

**AR 66 S A K D - PS 10 - 1**

(1) (2) (3) (4) (5) (6) (7) (8) (9) (10)

(1)	Series Name	<b>AR: AR Series</b>
(2)	Motor Frame Size	<b>2: 28 mm (30 mm) 4: 42 mm 6: 60 mm 9: 85 mm (90 mm)</b>
(3)	Motor Case Length	
(4)	Motor Classification	
(5)	Configuration	<b>A: Standard (Single shaft) B: Standard (Double shaft) M: Electromagnetic Brake Type</b>
(6)	Power Supply Input	<b>K: DC Power Supply</b>

(7)	Driver Type	<b>D: Built-in Controller Type Blank: Pulse Input Type</b>
(8)	Gear Type	<b>Blank: Standard Type T: TH Geared Type PS: PS Geared Type N: PN Geared Type H: Harmonic Geared Type</b>
(9)	Gear Ratio	
(10)	Cable Length (Included)	<b>1: 1 m 2: 2 m 3: 3 m</b>

## Product Line

### Built-in Controller Type

#### Standard Type

Product Name (Single shaft)	Product Name (Double shaft)
AR24SAKD-◇	AR24SBKD-◇
AR26SAKD-◇	AR26SBKD-◇
AR46SAKD-◇	AR46SBKD-◇
AR66SAKD-◇	AR66SBKD-◇
AR69SAKD-◇	AR69SBKD-◇
AR98SAKD-◇	AR98SBKD-◇

#### Standard Type with Electromagnetic Brake

Product Name
AR46SMKD-◇
AR66SMKD-◇
AR69SMKD-◇
AR98SMKD-◇

#### TH Geared Type

Product Name	Product Name
AR24SAKD-T7.2-◇	
AR24SAKD-T10-◇	
AR24SAKD-T20-◇	
AR24SAKD-T30-◇	

#### TH Geared Type with Electromagnetic Brake

Product Name
AR46SAKD-T3.6-◇
AR46SAKD-T7.2-◇
AR46SAKD-T10-◇
AR46SAKD-T20-◇
AR46SAKD-T30-◇
AR66SAKD-T3.6-◇
AR66SAKD-T7.2-◇
AR66SAKD-T10-◇
AR66SAKD-T20-◇
AR66SAKD-T30-◇
AR98SAKD-T3.6-◇
AR98SAKD-T7.2-◇
AR98SAKD-T10-◇
AR98SAKD-T20-◇
AR98SAKD-T30-◇

#### PS Geared Type

#### PS Geared Type with Electromagnetic Brake

Product Name	Product Name
AR24SAKD-PS5-◇	
AR24SAKD-PS7-◇	
AR24SAKD-PS10-◇	
AR46SAKD-PS5-◇	AR46SMKD-PS5-◇
AR46SAKD-PS7-◇	AR46SMKD-PS7-◇
AR46SAKD-PS10-◇	AR46SMKD-PS10-◇
AR46SAKD-PS25-◇	AR46SMKD-PS25-◇
AR46SAKD-PS36-◇	AR46SMKD-PS36-◇
AR46SAKD-PS50-◇	AR46SMKD-PS50-◇
AR66SAKD-PS5-◇	AR66SMKD-PS5-◇
AR66SAKD-PS7-◇	AR66SMKD-PS7-◇
AR66SAKD-PS10-◇	AR66SMKD-PS10-◇
AR66SAKD-PS25-◇	AR66SMKD-PS25-◇
AR66SAKD-PS36-◇	AR66SMKD-PS36-◇
AR66SAKD-PS50-◇	AR66SMKD-PS50-◇
AR98SAKD-PS5-◇	AR98SMKD-PS5-◇
AR98SAKD-PS7-◇	AR98SMKD-PS7-◇
AR98SAKD-PS10-◇	AR98SMKD-PS10-◇
AR98SAKD-PS25-◇	AR98SMKD-PS25-◇
AR98SAKD-PS36-◇	AR98SMKD-PS36-◇
AR98SAKD-PS50-◇	AR98SMKD-PS50-◇

#### PN Geared Type

#### PN Geared Type with Electromagnetic Brake

Product Name	Product Name
AR24SAKD-N5-◇	
AR24SAKD-N7.2-◇	
AR24SAKD-N10-◇	
AR46SAKD-N5-◇	AR46SMKD-N5-◇
AR46SAKD-N7.2-◇	AR46SMKD-N7.2-◇
AR46SAKD-N10-◇	AR46SMKD-N10-◇
AR66SAKD-N5-◇	AR66SMKD-N5-◇
AR66SAKD-N7.2-◇	AR66SMKD-N7.2-◇
AR66SAKD-N10-◇	AR66SMKD-N10-◇
AR66SAKD-N25-◇	AR66SMKD-N25-◇
AR66SAKD-N36-◇	AR66SMKD-N36-◇
AR66SAKD-N50-◇	AR66SMKD-N50-◇
AR98SAKD-N5-◇	AR98SMKD-N5-◇
AR98SAKD-N7.2-◇	AR98SMKD-N7.2-◇
AR98SAKD-N10-◇	AR98SMKD-N10-◇
AR98SAKD-N25-◇	AR98SMKD-N25-◇
AR98SAKD-N36-◇	AR98SMKD-N36-◇
AR98SAKD-N50-◇	AR98SMKD-N50-◇

Features

Lineup Configuration

Product Line

Specifications and Characteristics

Dimension and Operation

Connection and Operation

Extended Functions

How to Read Specifications and Characteristics

Accessory

Controller

## ◇ Harmonic Geared Type

## ◇ Harmonic Geared Type with Electromagnetic Brake

Product Name	Product Name
AR24SAKD-H50-◇	
AR24SAKD-H100-◇	—
AR46SAKD-H50-◇	AR46SMKD-H50-◇
AR46SAKD-H100-◇	AR46SMKD-H100-◇
AR66SAKD-H50-◇	AR66SMKD-H50-◇
AR66SAKD-H100-◇	AR66SMKD-H100-◇
AR98SAKD-H50-◇	AR98SMKD-H50-◇
AR98SAKD-H100-◇	AR98SMKD-H100-◇

● A number indicating the desired length of **1** (1 m), **2** (2 m) or **3** (3 m) for the cable included with the product is entered where the box ◇ is located within the product name.  
Select a desired cable length from 1 m, 2 m and 3 m.

## ● Pulse Input Type

## ◇ Standard Type

Product Name (Single shaft)	Product Name (Double shaft)
AR24SAK-◇	AR24SBK-◇
AR26SAK-◇	AR26SBK-◇
AR46SAK-◇	AR46SBK-◇
AR66SAK-◇	AR66SBK-◇
AR69SAK-◇	AR69SBK-◇
AR98SAK-◇	AR98SBK-◇

## ◇ Standard Type with Electromagnetic Brake

Product Name
AR46SMK-◇
AR66SMK-◇
AR69SMK-◇
AR98SMK-◇

## ◇ TH Geared Type

## ◇ TH Geared Type with Electromagnetic Brake

Product Name	Product Name
AR24SAK-T7.2-◇	
AR24SAK-T10-◇	—
AR24SAK-T20-◇	
AR24SAK-T30-◇	
AR46SAK-T3.6-◇	AR46SMK-T3.6-◇
AR46SAK-T7.2-◇	AR46SMK-T7.2-◇
AR46SAK-T10-◇	AR46SMK-T10-◇
AR46SAK-T20-◇	AR46SMK-T20-◇
AR46SAK-T30-◇	AR46SMK-T30-◇
AR66SAK-T3.6-◇	AR66SMK-T3.6-◇
AR66SAK-T7.2-◇	AR66SMK-T7.2-◇
AR66SAK-T10-◇	AR66SMK-T10-◇
AR66SAK-T20-◇	AR66SMK-T20-◇
AR66SAK-T30-◇	AR66SMK-T30-◇
AR98SAK-T3.6-◇	AR98SMK-T3.6-◇
AR98SAK-T7.2-◇	AR98SMK-T7.2-◇
AR98SAK-T10-◇	AR98SMK-T10-◇
AR98SAK-T20-◇	AR98SMK-T20-◇
AR98SAK-T30-◇	AR98SMK-T30-◇

## ◇ Harmonic Geared Type

## ◇ Harmonic Geared Type with Electromagnetic Brake

Product Name	Product Name
AR24SAK-H50-◇	
AR24SAK-H100-◇	—
AR46SAK-H50-◇	AR46SMK-H50-◇
AR46SAK-H100-◇	AR46SMK-H100-◇
AR66SAK-H50-◇	AR66SMK-H50-◇
AR66SAK-H100-◇	AR66SMK-H100-◇
AR98SAK-H50-◇	AR98SMK-H50-◇
AR98SAK-H100-◇	AR98SMK-H100-◇

● A number indicating the desired length of **1** (1 m), **2** (2 m) or **3** (3 m) for the cable included with the product is entered where the box ◇ is located within the product name.  
Select a desired cable length from 1 m, 2 m and 3 m.

The following items are included in each product.

Motor, Driver, Cable for Motor, Cable for Electromagnetic Brake\*, Connector for Input Signal, Connector for Output Signal, Sensor Signal Connector, Power Input Terminal Connector, Operating Manual

● The product comes with a 1 m, 2 m or 3 m cable for motor and cable for electromagnetic brake\*.

If you need cables longer than 3 m or cables offering excellent flexibility, select appropriate cables from the accessories (sold separately).

For details, refer to Page 55.

\*Only for electromagnetic brake type.

## ◇ PS Geared Type

## ◇ PS Geared Type with Electromagnetic Brake

Product Name	Product Name
AR24SAK-PS5-◇	
AR24SAK-PS7-◇	—
AR24SAK-PS10-◇	
AR46SAK-PS5-◇	AR46SMK-PS5-◇
AR46SAK-PS7-◇	AR46SMK-PS7-◇
AR46SAK-PS10-◇	AR46SMK-PS10-◇
AR46SAK-PS25-◇	AR46SMK-PS25-◇
AR46SAK-PS36-◇	AR46SMK-PS36-◇
AR46SAK-PS50-◇	AR46SMK-PS50-◇
AR66SAK-PS5-◇	AR66SMK-PS5-◇
AR66SAK-PS7-◇	AR66SMK-PS7-◇
AR66SAK-PS10-◇	AR66SMK-PS10-◇
AR66SAK-PS25-◇	AR66SMK-PS25-◇
AR66SAK-PS36-◇	AR66SMK-PS36-◇
AR66SAK-PS50-◇	AR66SMK-PS50-◇
AR98SAK-PS5-◇	AR98SMK-PS5-◇
AR98SAK-PS7-◇	AR98SMK-PS7-◇
AR98SAK-PS10-◇	AR98SMK-PS10-◇
AR98SAK-PS25-◇	AR98SMK-PS25-◇
AR98SAK-PS36-◇	AR98SMK-PS36-◇
AR98SAK-PS50-◇	AR98SMK-PS50-◇

## ◇ PN Geared Type

## ◇ PN Geared Type with Electromagnetic Brake

Product Name	Product Name
AR24SAK-N5-◇	
AR24SAK-N7.2-◇	—
AR24SAK-N10-◇	
AR46SAK-N5-◇	AR46SMK-N5-◇
AR46SAK-N7.2-◇	AR46SMK-N7.2-◇
AR46SAK-N10-◇	AR46SMK-N10-◇
AR66SAK-N5-◇	AR66SMK-N5-◇
AR66SAK-N7.2-◇	AR66SMK-N7.2-◇
AR66SAK-N10-◇	AR66SMK-N10-◇
AR66SAK-N25-◇	AR66SMK-N25-◇
AR66SAK-N36-◇	AR66SMK-N36-◇
AR66SAK-N50-◇	AR66SMK-N50-◇
AR98SAK-N5-◇	AR98SMK-N5-◇
AR98SAK-N7.2-◇	AR98SMK-N7.2-◇
AR98SAK-N10-◇	AR98SMK-N10-◇
AR98SAK-N25-◇	AR98SMK-N25-◇
AR98SAK-N36-◇	AR98SMK-N36-◇
AR98SAK-N50-◇	AR98SMK-N50-◇

The following items are included in each product.

Motor, Driver, Cable for Motor, Cable for Electromagnetic Brake\*, I/O signal Connector, Main Power Supply Input and Frame Ground Terminal Connectors, Surge Suppressor\*, Operating Manual

● The product comes with a 1 m, 2 m or 3 m cable for motor and cable for electromagnetic brake\*.

If you need cables longer than 3 m or cables offering excellent flexibility, select appropriate cables from the accessories (sold separately).

For details, refer to Page 55.

\*Only for electromagnetic brake type.

# Standard Type Frame Size 28 mm, 42 mm, 60 mm, 85 mm



## Specifications (RoHS)

Product Name	Built-in Controller	<b>AR24S□KD-◇</b>	<b>AR26S□KD-◇</b>	<b>AR46S□KD-◇</b>	<b>AR66S□KD-◇</b>	<b>AR69S□KD-◇</b>	<b>AR98S□KD-◇</b>
Pulse Input		<b>AR24S□K-◇</b>	<b>AR26S□K-◇</b>	<b>AR46S□K-◇</b>	<b>AR66S□K-◇</b>	<b>AR69S□K-◇</b>	<b>AR98S□K-◇</b>
Max. Holding Torque	N·m	0.055	0.12	0.3	1		2
Holding Torque at Motor Standstill	While Power is Supplied N·m	0.027	0.06	0.15	0.5		1
Electromagnetic Brake N·m		—	—	0.15	0.5		1
Rotor Inertial Moment	J: kg·m <sup>2</sup>	$11 \times 10^{-7}$	$20 \times 10^{-7}$	$58 \times 10^{-7}$ [ $73 \times 10^{-7}$ ]*1	$380 \times 10^{-7}$ [ $500 \times 10^{-7}$ ]*1	$750 \times 10^{-7}$ [ $870 \times 10^{-7}$ ]*1	$1100 \times 10^{-7}$ [ $1220 \times 10^{-7}$ ]*1
Resolution	When Set to 1000P/R			0.36°/Pulse			
Power Supply Input	Voltage	24 VDC±10% (24 VDC±5%)*2	24 VDC±10% (24 VDC±5%)*2/ 48 VDC±5%	24 VDC±10% (24 VDC±5%)*2/48 VDC±5%*3			
Input Current	A	0.9 (1.3)*2	1.4 (1.8)*2	3.1 (3.8)*2	3.0 (3.7)*2	2.5 (3.1)*2	
Electromagnetic Brake*4	Power Supply Input	—	24 VDC±5%*5 0.08A	24 VDC±5%*5 0.25A			

● Either **A** (single shaft), **B** (double shaft) or **M** (electromagnetic brake) indicating the configuration is entered where the box □ is located within the product name.

Either **A** (Single shaft) or **B** (Double shaft) indicating the configuration is entered in the box where □ is located within the **AR24** and **AR26** product names.

A number indicating the desired length of **1** (1 m), **2** (2 m) or **3** (3 m) for the cable included with the product is entered where the box ◇ is located within the product name.

\*1 The brackets [ ] indicate the specifications for the electromagnetic brake type.

\*2 The parentheses () indicate the specifications for the built-in controller type.


\*3 When the motor is operated from 48 VDC input, use an inertial load 10 times the rotor inertial ratio or less and twice the safety factor or more when calculating the acceleration torque.

\*4 For the pulse input type, a separate power supply for the electromagnetic brake is also required.


\*5 If the wiring distance between the motor and driver is extended to 20 m or longer using an accessory cable (sold separately), the 24 VDC±4% specification applies.

## Speed – Torque Characteristics


**AR24**




**AR26**




**AR46**




**AR66**



**AR69**



**AR98**



**Note**

Depending on the driving conditions, a considerable amount of heat may be generated by the motor. Be sure to keep the temperature of the motor case at approximately 100°C max.

Features

Lineup

System Configuration

Product Line

Specifications and Characteristics

Dimension

Connection and Operation

Combination List

Extended Functions

How to Read Specifications and Characteristics

Accessory

Controller

# TH Geared Type Frame Size 28 mm



## Specifications (RoHS)


Product Name	Built-in Controller	<b>AR24SAKD-T7.2-◇</b>	<b>AR24SAKD-T10-◇</b>	<b>AR24SAKD-T20-◇</b>	<b>AR24SAKD-T30-◇</b>
Pulse Input		<b>AR24SAK-T7.2-◇</b>	<b>AR24SAK-T10-◇</b>	<b>AR24SAK-T20-◇</b>	<b>AR24SAK-T30-◇</b>
Max. Holding Torque	N·m	0.2	0.3	0.4	0.5
Rotor Inertial Moment	J: kg·m <sup>2</sup>			$11 \times 10^{-7}$	
Gear Ratio		7.2	10	20	30
Resolution	When Set to 1000P/R	0.05°/Pulse	0.036°/Pulse	0.018°/Pulse	0.012°/Pulse
Permissible Torque	N·m	0.2	0.3	0.4	0.5
Holding Torque at Motor Standstill While Power is Supplied	N·m	0.13	0.19	0.38	0.5
Permissible Speed Range	r/min	0~416	0~300	0~150	0~100
Backlash	arc minute (degrees)			60(1°)	
Power Supply Input	Voltage			24 VDC±10% (24 VDC±5%)*	
	Input Current	A		0.9(1.3)*	

● A number indicating the desired length of 1 (1 m), 2 (2 m) or 3 (3 m) for the cable included with the product is entered where the box ◇ is located within the product name.


\*The parentheses () indicate the specifications for the built-in controller type.

## Speed – Torque Characteristics


**AR24** Gear Ratio 7.2




**AR24** Gear Ratio 10



**AR24** Gear Ratio 20



**AR24** Gear Ratio 30



**Note**

Depending on the driving conditions, a considerable amount of heat may be generated by the motor. Be sure to keep the temperature of the motor case at approximately 100°C max.

Features

Lineup

System Configuration

Product Line

Specifications and Characteristics

Dimension

Connection and Operation

Combination List

Extended Functions

How to Read Specifications and Characteristics

Accessory

Controller

CE

# TH Geared Type Frame Size 42 mm

CE

## Specifications (RoHS)

Product Name	Built-in Controller	AR46S□KD-T3.6-◇	AR46S□KD-T7.2-◇	AR46S□KD-T10-◇	AR46S□KD-T20-◇	AR46S□KD-T30-◇
Pulse Input		AR46S□K-T3.6-◇	AR46S□K-T7.2-◇	AR46S□K-T10-◇	AR46S□K-T20-◇	AR46S□K-T30-◇
Max. Holding Torque	N·m	0.35	0.7	1		1.5
Rotor Inertial Moment	J: kg·m <sup>2</sup>			58×10 <sup>-7</sup> [73×10 <sup>-7</sup> ]*1		
Gear Ratio		3.6	7.2	10	20	30
Resolution	When Set to 1000P/R	0.1°/Pulse	0.05°/Pulse	0.036°/Pulse	0.018°/Pulse	0.012°/Pulse
Permissible Torque	N·m	0.35	0.7	1		1.5
Holding Torque at Motor Standstill	While Power is Supplied N·m	0.33	0.67	0.93		1.5
Electromagnetic Brake	N·m	0.33	0.67	0.93		1.5
Permissible Speed Range	r/min	0~500	0~250	0~180	0~90	0~60
Backlash	arc minute (degrees)	45(0.75°)		25 (0.42°)		15 (0.25°)
Voltage				24 VDC±10% (24 VDC±5%)*2/48 VDC±5%		
Power Supply Input	Input Current	A		1.4 (1.8)*2		
Electromagnetic Brake*3	Power Supply Input			24 VDC±5%*4 0.08 A		

● Either **A** (single shaft) or **M** (electromagnetic brake) indicating the configuration is entered where the box □ is located within the product name.

A number indicating the desired length of **1** (1 m), **2** (2 m) or **3** (3 m) for the cable included with the product is entered where the box ◇ is located within the product name.

\*1 The brackets [ ] indicate the specifications for the electromagnetic brake type.


\*2 The parentheses () indicate the specifications for the built-in controller type.

\*3 For the pulse input type, a separate power supply for the electromagnetic brake is also required.


\*4 If the wiring distance between the motor and driver is extended to 20 m or longer using an accessory cable (sold separately), the 24 VDC±4% specification applies.

## Speed – Torque Characteristics


AR46 Gear Ratio 3.6




AR46 Gear Ratio 7.2




AR46 Gear Ratio 10



AR46 Gear Ratio 20



AR46 Gear Ratio 30



Note

Depending on the driving conditions, a considerable amount of heat may be generated by the motor. Be sure to keep the temperature of the motor case at approximately 100°C max.

Features

Lineup

System Configuration

Product Line

Specifications and Characteristics

Dimension

Connection and Operation

Combination List

Extended Functions

How to Read Specifications and Characteristics

Accessory

Controller

# TH Geared Type Frame Size 60 mm



## Specifications (RoHS)

Product Name	Built-in Controller	AR66S□KD-T3.6-◇	AR66S□KD-T7.2-◇	AR66S□KD-T10-◇	AR66S□KD-T20-◇	AR66S□KD-T30-◇
Pulse Input		AR66S□K-T3.6-◇	AR66S□K-T7.2-◇	AR66S□K-T10-◇	AR66S□K-T20-◇	AR66S□K-T30-◇
Max. Holding Torque	N·m	1.25	2.5	3	3.5	4
Rotor Inertial Moment	J: kg·m <sup>2</sup>			$380 \times 10^{-7} [500 \times 10^{-7}]^{\ast 1}$		
Gear Ratio		3.6	7.2	10	20	30
Resolution	When Set to 1000P/R	0.1°/Pulse	0.05°/Pulse	0.036°/Pulse	0.018°/Pulse	0.012°/Pulse
Permissible Torque	N·m	1.25	2.5	3	3.5	4
Holding Torque at Motor Standstill	While Power is Supplied N·m	1.1	2.2	3	3.5	4
Electromagnetic Brake	N·m	1.1	2.2	3	3.5	4
Permissible Speed Range	r/min	0~500	0~250	0~180	0~90	0~60
Backlash	arc minute (degrees)	35 (0.59°)		15 (0.25°)		10 (0.17°)
Power Supply Input	Voltage			24 VDC ±10% (24 VDC ±5%) <sup>＊2</sup> /48 VDC ±5% <sup>＊3</sup>		
	Input Current	A		3.1(3.8) <sup>＊2</sup>		
Electromagnetic Brake <sup>＊4</sup>	Power Supply Input			24 VDC ±5% <sup>＊5</sup>	0.25 A	

● Either **A** (single shaft) or **M** (electromagnetic brake) indicating the configuration is entered where the box □ is located within the product name.

A number indicating the desired length of **1** (1 m), **2** (2 m) or **3** (3 m) for the cable included with the product is entered where the box ◇ is located within the product name.

＊1 The brackets [ ] indicate the specifications for the electromagnetic brake type.

＊2 The parentheses () indicate the specifications for the built-in controller type.


＊3 When the motor is operated from 48 VDC input, use an inertial load 10 times the rotor inertial ratio or less and twice the safety factor or more when calculating the acceleration torque.

＊4 For the pulse input type, a separate power supply for the electromagnetic brake is also required.


＊5 If the wiring distance between the motor and driver is extended to 20 m or longer using an accessory cable (sold separately), the 24 VDC ±4% specification applies.

## Speed – Torque Characteristics


**AR66** Gear Ratio 3.6




**AR66** Gear Ratio 7.2




**AR66** Gear Ratio 10



**AR66** Gear Ratio 20



**AR66** Gear Ratio 30



**Note**

Depending on the driving conditions, a considerable amount of heat may be generated by the motor. Be sure to keep the temperature of the motor case at approximately 100°C max.

Features	Lineup	System Configuration	Product Line	Specifications and Characteristics	Dimension	Connection and Operation	Combination List	Extended Functions	How to Read Specifications and Characteristics	Accessory	Controller
----------	--------	----------------------	--------------	------------------------------------	-----------	--------------------------	------------------	--------------------	--	-----------	------------

# TH Geared Type Frame Size 90 mm



## Specifications (RoHS)

Product Name	Built-in Controller	AR98S□KD-T3.6-◇	AR98S□KD-T7.2-◇	AR98S□KD-T10-◇	AR98S□KD-T20-◇	AR98S□KD-T30-◇
Pulse Input		AR98S□K-T3.6-◇	AR98S□K-T7.2-◇	AR98S□K-T10-◇	AR98S□K-T20-◇	AR98S□K-T30-◇
Max. Holding Torque	N·m	4.5		9		12
Rotor Inertial Moment	J: kg·m <sup>2</sup>			1100×10 <sup>-7</sup> [1220×10 <sup>-7</sup> ]*1		
Gear Ratio		3.6	7.2	10	20	30
Resolution	When Set to 1000P/R	0.1°/Pulse	0.05°/Pulse	0.036°/Pulse	0.018°/Pulse	0.012°/Pulse
Permissible Torque	N·m	4.5		9		12
Holding Torque at Motor Standstill	While Power is Supplied N·m	3.6	7.2	9	12	
Electromagnetic Brake	N·m	3.6	7.2	9	12	
Permissible Speed Range	r/min	0~500	0~250	0~180	0~90	0~60
Backlash	arc minute (degrees)	25 (0.42°)		15 (0.25°)		10 (0.17°)
Voltage				24 VDC±10% (24 VDC±5%)*2/48 VDC±5%*3		
Power Supply Input	A			2.5(3.1)*2		
Electromagnetic Brake*4	Power Supply Input			24 VDC±5%*5	0.25 A	

● Either **A** (single shaft) or **M** (electromagnetic brake) indicating the configuration is entered where the box □ is located within the product name.

A number indicating the desired length of **1** (1 m), **2** (2 m) or **3** (3 m) for the cable included with the product is entered where the box ◇ is located within the product name.

\*1 The brackets [ ] indicate the specifications for the electromagnetic brake type.

\*2 The parentheses () indicate the specifications for the built-in controller type.


\*3 When the motor is operated from 48 VDC input, use an inertial load 10 times the rotor inertial ratio or less and twice the safety factor or more when calculating the acceleration torque.

\*4 For the pulse input type, a separate power supply for the electromagnetic brake is also required.


\*5 If the wiring distance between the motor and driver is extended to 20 m or longer using an accessory cable (sold separately), the 24 VDC±4% specification applies.

## Speed – Torque Characteristics


AR98 Gear Ratio 3.6




AR98 Gear Ratio 7.2




AR98 Gear Ratio 10



AR98 Gear Ratio 20



AR98 Gear Ratio 30



Note

Depending on the driving conditions, a considerable amount of heat may be generated by the motor. Be sure to keep the temperature of the motor case at approximately 100°C max.

Features

Lineup

System Configuration

Product Line

Specifications and Characteristics

Dimension

Connection and Operation

Combination List

Extended Functions

How to Read Specifications and Characteristics

Accessory

Controller

# PS Geared Type Frame Size 28 mm



## Specifications (RoHS)


Product Name	Built-in Controller	<b>AR24SAKD-PS5-◇</b>	<b>AR24SAKD-PS7-◇</b>	<b>AR24SAKD-PS10-◇</b>
	Pulse Input	<b>AR24SAK-PS5-◇</b>	<b>AR24SAK-PS7-◇</b>	<b>AR24SAK-PS10-◇</b>
Max. Holding Torque	N·m	0.2	0.3	0.5
Rotor Inertial Moment	J: kg·m <sup>2</sup>		$11 \times 10^{-7}$	
Gear Ratio		5	7.2	10
Resolution	When Set to 1000P/R	0.072/Pulse	0.057/Pulse	0.0367/Pulse
Permissible Torque	N·m	0.2	0.3	0.5
Maximum Torque	N·m		0.5	
Holding Torque at Motor Standstill While Power is Supplied	N·m	0.13	0.19	0.27
Permissible Speed Range	r/min	0~600	0~416	0~300
Backlash	arc minute (degrees)		35 (0.59°)	
Power Supply Input	Voltage		24 VDC±10% (24 VDC±5%)*	
	Input Current	A	0.9(1.3)*	

● A number indicating the desired length of **1** (1 m), **2** (2 m) or **3** (3 m) for the cable included with the product is entered where the box ◇ is located within the product name.


\*The parentheses () indicate the specifications for the built-in controller type.

## Speed – Torque Characteristics


**AR24** Gear Ratio 5



**AR24** Gear Ratio 7.2



**AR24** Gear Ratio 10



**Note**

● Depending on the driving conditions, a considerable amount of heat may be generated by the motor. Be sure to keep the temperature of the motor case at approximately 100°C max.

Features

Lineup

System Configuration

Product Line  
Specifications and Characteristics

Dimension

Connection and Operation

Combination List

Extended Functions

How to Read Specifications and Characteristics

Accessory Controller

# PS Geared Type Frame Size 42 mm



## Specifications (RoHS)

Product Name	Built-in Controller	AR46S□KD-PS5-◇	AR46S□KD-PS7-◇	AR46S□KD-PS10-◇	AR46S□KD-PS25-◇	AR46S□KD-PS36-◇	AR46S□KD-PS50-◇
Pulse Input	AR46S□K-PS5-◇	AR46S□K-PS7-◇	AR46S□K-PS10-◇	AR46S□K-PS25-◇	AR46S□K-PS36-◇	AR46S□K-PS50-◇	
Max. Holding Torque	N·m	1		1.5	2.5		3
Rotor Inertial Moment	J: kg·m <sup>2</sup>			58×10 <sup>-7</sup> [73×10 <sup>-7</sup> ]*1			
Gear Ratio		5	7.2	10	25	36	50
Resolution	When Set to 1000P/R	0.072°/Pulse	0.05°/Pulse	0.036°/Pulse	0.0144°/Pulse	0.01°/Pulse	0.0072°/Pulse
Permissible Torque	N·m	1		1.5	2.5		3
Maximum Torque	N·m	1.5		2		6	
Holding Torque at Motor Standstill	N·m	0.75	1	1.5	2.5	3	
Electromagnetic Brake	N·m	0.75	1	1.5	2.5	3	
Permissible Speed Range	r/min	0~600	0~416	0~300	0~120	0~83	0~60
Backlash	arc minute (degrees)			25 (0.42°)			
Power Supply Input	Voltage			24 VDC±10% (24 VDC±5%)*2/48 VDC±5%			
	Input Current	A		1.4(1.8)*2			
Electromagnetic Brake*3	Power Supply Input			24 VDC±5%*4 0.08 A			

● Either **A** (single shaft) or **M** (electromagnetic brake) indicating the configuration is entered where the box □ is located within the product name.

A number indicating the desired length of **1** (1 m), **2** (2 m) or **3** (3 m) for the cable included with the product is entered where the box ◇ is located within the product name.

\*1 The brackets [ ] indicate the specifications for the electromagnetic brake type.


\*2 The parentheses () indicate the specifications for the built-in controller type.

\*3 For the pulse input type, a separate power supply for the electromagnetic brake is also required.


\*4 If the wiring distance between the motor and driver is extended to 20 m or longer using an accessory cable (sold separately), the 24 VDC±4% specification applies.

## Speed – Torque Characteristics


AR46 Gear Ratio 5




AR46 Gear Ratio 7.2




AR46 Gear Ratio 10




AR46 Gear Ratio 25



AR46 Gear Ratio 36



AR46 Gear Ratio 50



Note

Depending on the driving conditions, a considerable amount of heat may be generated by the motor. Be sure to keep the temperature of the motor case at approximately 100°C max.

Features

Lineup  
Configuration

Product Line

Specifications  
and  
Characteristics

Dimension

Connection  
and  
Operation

Combination  
List

Extended  
Functions

How to Read  
Specifications and  
Characteristics

Accessory

Controller

# PS Geared Type Frame Size 60 mm



## Specifications (RoHS)

Product Name	Built-in Controller	AR66S□KD-PS5-◇	AR66S□KD-PS7-◇	AR66S□KD-PS10-◇	AR66S□KD-PS25-◇	AR66S□KD-PS36-◇	AR66S□KD-PS50-◇
Pulse Input		AR66S□K-PS5-◇	AR66S□K-PS7-◇	AR66S□K-PS10-◇	AR66S□K-PS25-◇	AR66S□K-PS36-◇	AR66S□K-PS50-◇
Max. Holding Torque	N·m	3.5		5		8	
Rotor Inertial Moment	J: kg·m <sup>2</sup>			380×10 <sup>-7</sup> [500×10 <sup>-7</sup> ]*1			
Gear Ratio		5	7.2	10	25	36	50
Resolution	When Set to 1000P/R	0.072°/Pulse	0.05°/Pulse	0.036°/Pulse	0.0144°/Pulse	0.01°/Pulse	0.0072°/Pulse
Permissible Torque	N·m	3.5	4	5		8	
Maximum Torque	N·m	7	9	11	16	20	
Holding Torque at Motor Standstill	N·m	2.5	3.6	5	7.6	8	
Electromagnetic Brake N·m		2.5	3.6	5	7.6	8	
Permissible Speed Range	r/min	0~600	0~416	0~300	0~120	0~83	0~60
Backlash	arc minute (degrees)			15 (0.25°)			
Power Supply Input	Voltage			24 VDC±10% (24 VDC±5%)*2/48 VDC±5%*3			
	Input Current	A			3.1(3.8)*2		
Electromagnetic Brake*4	Power Supply Input			24 VDC±5%*5	0.25 A		

● Either **A** (single shaft) or **M** (electromagnetic brake) indicating the configuration is entered where the box □ is located within the product name.

A number indicating the desired length of **1** (1 m), **2** (2 m) or **3** (3 m) for the cable included with the product is entered where the box ◇ is located within the product name.

\*1 The brackets [ ] indicate the specifications for the electromagnetic brake type.

\*2 The parentheses () indicate the specifications for the built-in controller type.


\*3 When the motor is operated from 48 VDC input, use an inertial load 10 times the rotor inertial ratio or less and twice the safety factor or more when calculating the acceleration torque.

\*4 For the pulse input type, a separate power supply for the electromagnetic brake is also required.


\*5 If the wiring distance between the motor and driver is extended to 20 m or longer using an accessory cable (sold separately), the 24 VDC±4% specification applies.

## Speed – Torque Characteristics


**AR66** Gear Ratio 5




**AR66** Gear Ratio 7.2




**AR66** Gear Ratio 10




**AR66** Gear Ratio 25



**AR66** Gear Ratio 36



**AR66** Gear Ratio 50



**Note**

Depending on the driving conditions, a considerable amount of heat may be generated by the motor. Be sure to keep the temperature of the motor case at approximately 100°C max.

Features

Lineup

Configuration

Product Line

Specifications and Characteristics

Dimension

Connection and Operation

Combination List

How to Read Specifications and Characteristics

Accessory Controller

# PS Geared Type Frame Size 90 mm



## Specifications (RoHS)

Product Name	Built-in Controller	AR98S□KD-PS5-◇	AR98S□KD-PS7-◇	AR98S□KD-PS10-◇	AR98S□KD-PS25-◇	AR98S□KD-PS36-◇	AR98S□KD-PS50-◇
Pulse Input		AR98S□K-PS5-◇	AR98S□K-PS7-◇	AR98S□K-PS10-◇	AR98S□K-PS25-◇	AR98S□K-PS36-◇	AR98S□K-PS50-◇
Max. Holding Torque	N·m	10	14	20		37	
Rotor Inertial Moment	J: kg·m <sup>2</sup>				1100×10 <sup>-7</sup> [1220×10 <sup>-7</sup> ]*1		
Gear Ratio		5	7.2	10	25	36	50
Resolution	When Set to 1000P/R	0.072°/Pulse	0.05°/Pulse	0.036°/Pulse	0.0144°/Pulse	0.01°/Pulse	0.0072°/Pulse
Permissible Torque	N·m	10	14	20		37	
Maximum Torque	N·m	28		35		56	60
Holding Torque at Motor Standstill	N·m	5	7.2	10	25	36	37
Electromagnetic Brake	N·m	5	7.2	10	25	36	37
Permissible Speed Range	r/min	0~400	0~277	0~200	0~80	0~55	0~40
Backlash	arc minute (degrees)				15 (0.25°)		
Power Supply Input	Voltage				24 VDC±10% (24 VDC±5%)*2/48 VDC±5%*3		
	Input Current	A			2.5(3.1)*2		
Electromagnetic Brake*4	Power Supply Input				24 VDC±5%*5 0.25 A		

● Either **A** (single shaft) or **M** (electromagnetic brake) indicating the configuration is entered where the box □ is located within the product name.

A number indicating the desired length of **1** (1 m), **2** (2 m) or **3** (3 m) for the cable included with the product is entered where the box ◇ is located within the product name.

\*1 The brackets [ ] indicate the specifications for the electromagnetic brake type.

\*2 The parentheses () indicate the specifications for the built-in controller type.


\*3 When the motor is operated from 48 VDC input, use an inertial load 10 times the rotor inertial ratio or less and twice the safety factor or more when calculating the acceleration torque.

\*4 For the pulse input type, a separate power supply for the electromagnetic brake is also required.


\*5 If the wiring distance between the motor and driver is extended to 20 m or longer using an accessory cable (sold separately), the 24 VDC±4% specification applies.

## Speed – Torque Characteristics


AR98 Gear Ratio 5




AR98 Gear Ratio 7.2




AR98 Gear Ratio 10




AR98 Gear Ratio 25



AR98 Gear Ratio 36



AR98 Gear Ratio 50



Note

Depending on the driving conditions, a considerable amount of heat may be generated by the motor. Be sure to keep the temperature of the motor case at approximately 100°C max.

Features

Lineup Configuration Product Line

Specifications and Characteristics

Dimension Connection and Operation

Combination Extended Functions

How to Read Specifications and Accessory Controller

# PN Geared Type Frame Size 28 mm



## Specifications (RoHS)


Product Name	Built-in Controller	<b>AR24SAKD-N5-◇</b>	<b>AR24SAKD-N7.2-◇</b>	<b>AR24SAKD-N10-◇</b>
Pulse Input		<b>AR24SAK-N5-◇</b>	<b>AR24SAK-N7.2-◇</b>	<b>AR24SAK-N10-◇</b>
Max. Holding Torque	N·m	0.2	0.3	0.5
Rotor Inertial Moment	J: kg·m <sup>2</sup>		$11 \times 10^{-7}$	
Gear Ratio		5	7.2	10
Resolution	When Set to 1000P/R	0.072/Pulse	0.057/Pulse	0.0367/Pulse
Permissible Torque	N·m	0.2	0.3	0.5
Maximum Torque	N·m		0.5	
Holding Torque at Motor Standstill While Power is Supplied	N·m	0.13	0.19	0.27
Permissible Speed Range	r/min	0~600	0~416	0~300
Backlash	arc minute (degrees)		3(0.05°)	
Power Supply Input	Voltage		24 VDC±10% (24 VDC±5%)*	
	Input Current	A	0.9(1.3)*	

● A number indicating the desired length of **1** (1 m), **2** (2 m) or **3** (3 m) for the cable included with the product is entered where the box ◇ is located within the product name.


\* The parentheses () indicate the specifications for the built-in controller type.

## Speed – Torque Characteristics


**AR24** Gear Ratio 5



**AR24** Gear Ratio 7.2



**AR24** Gear Ratio 10



**Note**

● Depending on the driving conditions, a considerable amount of heat may be generated by the motor. Be sure to keep the temperature of the motor case at approximately 100°C max.

Features

Lineup

System Configuration

Product Line  
Specifications and Characteristics

Dimension

Connection and Operation

Combination List

Extended Functions

How to Read Specifications and Characteristics

Accessory Controller

# PN Geared Type Frame Size 42 mm



## Specifications (RoHS)

Product Name	Built-in Controller	<b>AR46S□KD-N5-◇</b>	<b>AR46S□KD-N7.2-◇</b>	<b>AR46S□KD-N10-◇</b>
Pulse Input		<b>AR46S□K-N5-◇</b>	<b>AR46S□K-N7.2-◇</b>	<b>AR46S□K-N10-◇</b>
Max. Holding Torque	N·m	1.35		1.5
Rotor Inertial Moment	J: kg·m <sup>2</sup>		$58 \times 10^{-7} [73 \times 10^{-7}]^{\ast 1}$	
Gear Ratio		5	7.2	10
Resolution	When Set to 1000P/R	0.072°/Pulse	0.05°/Pulse	0.036°/Pulse
Permissible Torque	N·m	1.35		1.5
Maximum Torque	N·m	1.5		2
Holding Torque at Motor Standstill	While Power is Supplied N·m	0.75	1	1.5
Electromagnetic Brake	N·m	0.75	1	1.5
Permissible Speed Range	r/min	0~600	0~416	0~300
Backlash	arc minute (degrees)		2(0.034°)	
Power Supply Input	Voltage		24 VDC±10% (24 VDC±5%) <sup>\ast 2</sup> /48 VDC±5%	
	Input Current	A	1.4(1.8) <sup>\ast 2</sup>	
Electromagnetic Brake <sup>\ast 3</sup>	Power Supply Input		24 VDC±5% <sup>\ast 4</sup>	0.08 A

● Either **A** (single shaft) or **M** (electromagnetic brake) indicating the configuration is entered where the box □ is located within the product name.

A number indicating the desired length of **1** (1 m), **2** (2 m) or **3** (3 m) for the cable included with the product is entered where the box ◇ is located within the product name.

<sup>\ast 1</sup> The brackets [ ] indicate the specifications for the electromagnetic brake type.


<sup>\ast 2</sup> The parentheses () indicate the specifications for the built-in controller type.

<sup>\ast 3</sup> For the pulse input type, a separate power supply for the electromagnetic brake is also required.


<sup>\ast 4</sup> If the wiring distance between the motor and driver is extended to 20 m or longer using an accessory cable (sold separately), the 24 VDC±4% specification applies.

## Speed – Torque Characteristics


**AR46** Gear Ratio 5



**AR46** Gear Ratio 7.2



**AR46** Gear Ratio 10



**Note**

Depending on the driving conditions, a considerable amount of heat may be generated by the motor. Be sure to keep the temperature of the motor case at approximately 100°C max.

Features

Lineup

Configuration

Product Line

Specifications and Characteristics

Dimension

Connection and Operation

Extended Functions

How to Read Specifications and Characteristics

Accessory

Controller

# PN Geared Type Frame Size 60 mm



## Specifications (RoHS)

Product Name	Built-in Controller	AR66S□KD-N5-◇	AR66S□KD-N7.2-◇	AR66S□KD-N10-◇	AR66S□KD-N25-◇	AR66S□KD-N36-◇	AR66S□KD-N50-◇
Pulse Input		AR66S□K-N5-◇	AR66S□K-N7.2-◇	AR66S□K-N10-◇	AR66S□K-N25-◇	AR66S□K-N36-◇	AR66S□K-N50-◇
Max. Holding Torque	N·m	3.5	4	5		8	
Rotor Inertial Moment	J: kg·m <sup>2</sup>			380×10 <sup>-7</sup> [500×10 <sup>-7</sup> ]*1			
Gear Ratio		5	7.2	10	25	36	50
Resolution	When Set to 1000P/R	0.072°/Pulse	0.05°/Pulse	0.036°/Pulse	0.0144°/Pulse	0.01°/Pulse	0.0072°/Pulse
Permissible Torque	N·m	3.5	4	5		8	
Maximum Torque	N·m	7	9	11	16	20	
Holding Torque at Motor Standstill	While Power is Supplied N·m	2.5	3.6	5	7.6	8	
Electromagnetic Brake	N·m	2.5	3.6	5	7.6	8	
Permissible Speed Range	r/min	0~600	0~416	0~300	0~120	0~83	0~60
Backlash	arc minute (degrees)		2(0.034°)			3(0.05°)	
Power Supply Input	Voltage			24 VDC±10% (24 VDC±5%)*2/48 VDC±5%*3			
	Input Current	A			3.1(3.8)*2		
Electromagnetic Brake*4	Power Supply Input			24 VDC±5%*5	0.25 A		

● Either **A** (single shaft) or **M** (electromagnetic brake) indicating the configuration is entered where the box □ is located within the product name.

A number indicating the desired length of **1** (1 m), **2** (2 m) or **3** (3 m) for the cable included with the product is entered where the box ◇ is located within the product name.

\*1 The brackets [ ] indicate the specifications for the electromagnetic brake type.

\*2 The parentheses () indicate the specifications for the built-in controller type.


\*3 When the motor is operated from 48 VDC input, use an inertial load 10 times the rotor inertial ratio or less and twice the safety factor or more when calculating the acceleration torque.

\*4 For the pulse input type, a separate power supply for the electromagnetic brake is also required.


\*5 If the wiring distance between the motor and driver is extended to 20 m or longer using an accessory cable (sold separately), the 24 VDC±4% specification applies.

## Speed – Torque Characteristics


**AR66** Gear Ratio 5




**AR66** Gear Ratio 7.2




**AR66** Gear Ratio 10




**AR66** Gear Ratio 25



**AR66** Gear Ratio 36



**AR66** Gear Ratio 50



**Note**

Depending on the driving conditions, a considerable amount of heat may be generated by the motor. Be sure to keep the temperature of the motor case at approximately 100°C max.

Features

Lineup

Configuration

Product Line

Specifications and Characteristics

Dimension

Connection and Operation

Combination List

How to Read Specifications and Characteristics

Accessory Controller

# PN Geared Type Frame Size 90 mm



## Specifications (RoHS)

Product Name	Built-in Controller	AR98S□KD-N5-◇	AR98S□KD-N7.2-◇	AR98S□KD-N10-◇	AR98S□KD-N25-◇	AR98S□KD-N36-◇	AR98S□KD-N50-◇
Pulse Input		AR98S□K-N5-◇	AR98S□K-N7.2-◇	AR98S□K-N10-◇	AR98S□K-N25-◇	AR98S□K-N36-◇	AR98S□K-N50-◇
Max. Holding Torque	N·m	10	14	20		37	
Rotor Inertial Moment	J: kg·m <sup>2</sup>			1100×10 <sup>-7</sup> [1220×10 <sup>-7</sup> ]*1			
Gear Ratio		5	7.2	10	25	36	50
Resolution	When Set to 1000P/R	0.072°/Pulse	0.05°/Pulse	0.036°/Pulse	0.0144°/Pulse	0.01°/Pulse	0.0072°/Pulse
Permissible Torque	N·m	10	14	20		37	
Maximum Torque	N·m	28		35	56		60
Holding Torque at Motor Standstill	N·m	5	7.2	10	25	36	37
Electromagnetic Brake	N·m	5	7.2	10	25	36	37
Permissible Speed Range	r/min	0~400	0~277	0~200	0~80	0~55	0~40
Backlash	arc minute (degrees)		2(0.034°)			3(0.05°)	
Power Supply Input	Voltage			24 VDC±10% (24 VDC±5%)*2/48 VDC±5%*3			
	Input Current	A		2.5(3.1)*2			
Electromagnetic Brake*4	Power Supply Input			24 VDC±5%*5	0.25 A		

● Either **A** (single shaft) or **M** (electromagnetic brake) indicating the configuration is entered where the box □ is located within the product name.

A number indicating the desired length of **1** (1 m), **2** (2 m) or **3** (3 m) for the cable included with the product is entered where the box ◇ is located within the product name.

\*1 The brackets [ ] indicate the specifications for the electromagnetic brake type.

\*2 The parentheses () indicate the specifications for the built-in controller type.


\*3 When the motor is operated from 48 VDC input, use an inertial load 10 times the rotor inertial ratio or less and twice the safety factor or more when calculating the acceleration torque.

\*4 For the pulse input type, a separate power supply for the electromagnetic brake is also required.


\*5 If the wiring distance between the motor and driver is extended to 20 m or longer using an accessory cable (sold separately), the 24 VDC±4% specification applies.

## Speed – Torque Characteristics


AR98 Gear Ratio 5




AR98 Gear Ratio 7.2




AR98 Gear Ratio 10




AR98 Gear Ratio 25



AR98 Gear Ratio 36



AR98 Gear Ratio 50



### Note

Depending on the driving conditions, a considerable amount of heat may be generated by the motor. Be sure to keep the temperature of the motor case at approximately 100°C max.

Features

Lineup  
Configuration

Product Line  
Specifications and Characteristics

Dimension  
Connection and Operation

Combination List  
Extended Functions

How to Read Specifications and Characteristics

Accessory  
Controller

# Harmonic Geared Type Frame Size 30 mm, 42 mm

## Specifications (RoHS)

Product Name	Built-in Controller	<b>AR24SAKD-H50-◇</b>	<b>AR24SAKD-H100-◇</b>	<b>AR46SKD-H50-◇</b>	<b>AR46SKD-H100-◇</b>
Pulse Input		<b>AR24SAK-H50-◇</b>	<b>AR24SAK-H100-◇</b>	<b>AR46SK-K-H50-◇</b>	<b>AR46SK-K-H100-◇</b>
Max. Holding Torque	N·m	1.8	2.4	3.5	5
Rotor Inertial Moment	J: kg·m <sup>2</sup>		$14 \times 10^{-7}$		$75 \times 10^{-7} [90 \times 10^{-7}]^*$
Gear Ratio		50	100	50	100
Resolution	When Set to 1000P/R	0.0072°/Pulse	0.0036°/Pulse	0.0072°/Pulse	0.0036°/Pulse
Permissible Torque	N·m	1.8	2.4	3.5	5
Maximum Torque	N·m	3.3	4.8	8.3	11
Holding Torque at Motor Standstill	While Power is Supplied N·m	1.3	2.4	3.5	5
Electromagnetic Brake	N·m	—	—	3.5	5
Permissible Speed Range	r/min	0~70	0~35	0~70	0~35
Lost Motion (Load torque)	arc minute (degrees)	1.5 or less ( $\pm 0.09$ N·m)	1.5 or less ( $\pm 0.12$ N·m)	1.5 or less ( $\pm 0.16$ N·m)	1.5 or less ( $\pm 0.2$ N·m)
Power Supply Input	Voltage	24 VDC ± 10% (24 VDC ± 5%) <sup>*2</sup>		24 VDC ± 10% (24 VDC ± 5%) <sup>*2</sup> /48 VDC ± 5%	
	Input Current	A	0.9(1.3) <sup>*2</sup>		1.4(1.8) <sup>*2</sup>
Electromagnetic Brake <sup>*3</sup>	Power Supply Input	—	—	24 VDC ± 5% <sup>*4</sup>	0.08 A

● Either **A** (single shaft) or **M** (electromagnetic brake) indicating the configuration is entered where the box □ is located within the product name.

A number indicating the desired length of **1** (1 m), **2** (2 m) or **3** (3 m) for the cable included with the product is entered where the box ◇ is located within the product name.

\*1 The brackets [ ] indicate the specifications for the electromagnetic brake type.


\*2 The parentheses () indicate the specifications for the built-in controller type.

\*3 For the pulse input type, a separate power supply for the electromagnetic brake is also required.


\*4 If the wiring distance between the motor and driver is extended to 20 m or longer using an accessory cable (sold separately), the 24 VDC ± 4% specification applies.

## Speed – Torque Characteristics


**AR24** Gear Ratio 50




**AR24** Gear Ratio 100



**AR46** Gear Ratio 50



**AR46** Gear Ratio 100



**Note**

- Depending on the driving conditions, a considerable amount of heat may be generated by the motor. Be sure to keep the temperature of the motor case at approximately 100°C max.
- In order to prevent deterioration of the gear grease in the harmonic geared type, keep the temperature of the gear case at 70°C max.

Features

Lineup Configuration Product Line

Specifications and Characteristics

Dimension

Connection and Operation

Combination List

Extended Functions How to Read Specifications and Characteristics

Accessory Controller

# Harmonic Geared Type Frame Size 60 mm, 90 mm



## Specifications (RoHS)

Product Name	Built-in Controller	AR66S□KD-H50-◇	AR66S□KD-H100-◇	AR98S□KD-H50-◇	AR98S□KD-H100-◇
Pulse Input		AR66S□K-H50-◇	AR66S□K-H100-◇	AR98S□K-H50-◇	AR98S□K-H100-◇
Max. Holding Torque	N·m	5.5	8	25	37
Rotor Inertial Moment	J: kg·m <sup>2</sup>	$415 \times 10^{-7}$ [ $535 \times 10^{-7}$ ]*1		$1300 \times 10^{-7}$ [ $1420 \times 10^{-7}$ ]*1	
Gear Ratio		50	100	50	100
Resolution	When Set to 1000P/R	0.0072°/Pulse	0.0036°/Pulse	0.0072°/Pulse	0.0036°/Pulse
Permissible Torque	N·m	5.5	8	25	37
Maximum Torque	N·m	18	28	35	55
Holding Torque at Motor Standstill	N·m	5.5	8	25	37
Electromagnetic Brake	N·m	5.5	8	25	37
Permissible Speed Range	r/min	0~60	0~30	0~40	0~20
Lost Motion (Load torque)	arc minute (degrees)	0.7 or less ( $\pm 0.28$ N·m)	0.7 or less ( $\pm 0.39$ N·m)	1.5 or less ( $\pm 1.2$ N·m)	
Power Supply Input	Voltage		24 VDC±10% (24 VDC±5%)*2/48 VDC±5%*3		
	Input Current	A	3.1(3.8)*2		2.5(3.1)*2
Electromagnetic Brake*4	Power Supply Input			24 VDC±5%*5	0.25 A

● Either **A** (single shaft) or **M** (electromagnetic brake) indicating the configuration is entered where the box □ is located within the product name.

A number indicating the desired length of **1** (1 m), **2** (2 m) or **3** (3 m) for the cable included with the product is entered where the box ◇ is located within the product name.

\*1 The brackets [ ] indicate the specifications for the electromagnetic brake type.

\*2 The parentheses () indicate the specifications for the built-in controller type.


\*3 When the motor is operated from 48 VDC input, use an inertial load 10 times the rotor inertial ratio or less and twice the safety factor or more when calculating the acceleration torque.

\*4 For the pulse input type, a separate power supply for the electromagnetic brake is also required.


\*5 If the wiring distance between the motor and driver is extended to 20 m or longer using an accessory cable (sold separately), the 24 VDC±4% specification applies.

## Speed – Torque Characteristics


AR66 Gear Ratio 50




AR66 Gear Ratio 100



AR98 Gear Ratio 50



AR98 Gear Ratio 100



Note

- Depending on the driving conditions, a considerable amount of heat may be generated by the motor. Be sure to keep the temperature of the motor case at approximately 100°C max.
- In order to prevent deterioration of the gear grease in the harmonic geared type, keep the temperature of the gear case at 70°C max.

Features

Lineup

System Configuration

Product Line

Specifications and Characteristics

Dimension

Connection and Operation

Combination List

Extended Functions

How to Read Specifications and Characteristics

Accessory

Controller

## Driver Specifications

	Built-in Controller Type	Pulse Input Type
Max. Input Pulse Frequency	—	When the programmable controller is generating line driver output: 500 kHz (Duty: 50%) When the programmable controller is generating open-collector output: 250kHz (Duty: 50%)*
Positioning Data	64 Points	—
Positioning Operation	Independent	○
	Linked	○
	Linked 2	○
	Sequential	○
	Direct	○
	Pushing	○
Continuous Operation	○	—
JOG Operation	○	—
Return-To-Home Operation	○	—
Test Operation	○	○
Absolute Backup System	○	—
Control Module <b>OPX-2A</b>	○	○
Data Setting Software <b>MEXEO2</b>	○	○

\* A value when the general-purpose cable (**CC36D1-1**) sold separately was used. General purpose cable → Page 58

## Built-in Controller Type RS-485 Communication Specifications

Protocol	Modbus protocol (Modbus RTU mode)
Electrical Characteristics	EIA-485 conformance Use a twisted-pair cable (TIA/EIA-568B CAT5e or better recommended). The total extension length must be 50 m or less.
Transmission Method	Half duplex
Baud Rate	9600 bps/19200 bps/38400 bps/57600 bps/115200 bps
Physical Layer	Start-stop synchronization (data length: 8 bits, stop bits: 1 or 2 bits, parity: none, even, or odd)
Connection Type	Up to 31 drivers can be connected to a single programmable controller (master equipment).

## General Specifications


	Motor	Driver	
		Built-in Controller Type	Pulse Input Type
Heat Resistance Class	130 (B)	—	—
Insulation Resistance	100 MΩ min. when measured with a 500 VDC megger between the following locations: • Case - Motor and Sensor Windings • Case - Electromagnetic Brake Windings	100 MΩ min. when measured with a 500 VDC megger between the following locations: • FG terminal - Power input terminal	—
Dielectric Strength	No abnormality is judged with the following application for 1 minute: • Case - Motor and Sensor Windings 1.0 kV at 50 Hz or 60 Hz • Case - Electromagnetic Brake Windings 1.0 kV at 50 Hz or 60 Hz	No abnormality is judged with the following application for 1 minute: • FG terminal - Power input terminal 500 VAC at 50 Hz or 60 Hz	—
Operating Environment (In operation)	Ambient Temperature	−10~+50°C (non-freezing)*1: Standard Type, <b>TH</b> , <b>PS</b> and <b>PN</b> Geared Types 0~+40°C (non-freezing)*1: Harmonic Geared Type	0~+50°C (non-freezing)
	Ambient Humidity	85% max. (non-condensing)	—
	Atmosphere	Use in an area without corrosive gases and dust. The product should not be exposed to water, oil or other liquids.	—
Degree of Protection	IP20	IP10	IP20
Stop Position Accuracy	<b>AR24, AR26, AR46:</b> ±4 minutes (±0.067°) <b>AR66, AR69, AR98:</b> ±3 minutes (±0.05°)		
Shaft Runout	0.05 T. I. R. (mm)*2	—	—
Concentricity of Installing Pilot to the Shaft	0.075 T. I. R. (mm)*2	—	—
Perpendicularity of Installation Surface to the Shaft	0.075 T. I. R. (mm)*2	—	—

\*1 When a heat sink of a capacity at least equivalent to an aluminum plate with a size of 100×100 mm, 6 mm thick is installed

\*2 T. I. R. (Total Indicator Reading): The total dial gauge reading when the measurement section is rotated one revolution centered on the reference axis center.

**Note**

● Do not perform the insulation resistance test or dielectric voltage withstand test while the motor and driver are connected.



Features	Lineup	System Configuration	Product Line	Specifications and Characteristics
				Dimension
				Connection and Operation
				Combination List
				Extended Functions
				How to Read Specifications and Characteristics
				Accessory
				Controller

## Load Torque – Driver Input Current Characteristics


This is the relationship between the load torque and driver input current at each speed when the motor is actually operated. From these characteristics, the power supply capacity required for use in multi-axis operation can be estimated. For the geared type, convert to torque and speed at the motor shaft.

Motor shaft speed = Gear output shaft speed × Gear ratio [r/min]


$$\text{Motor shaft torque} = \frac{\text{Gear output shaft torque}}{\text{Gear ratio}} \quad [\text{N}\cdot\text{m}]$$

**24 VDC**


**AR24**




**AR26**




**AR46**




**AR66**



**AR69**




**AR98**




**48 VDC**


**AR46**



**AR66**



**AR69**



**AR98**



Features

Lineup

System Configuration

Product Line

Specifications and Characteristics

Dimension Connection and Operation

Combination List Extended Functions

How to Read Specifications and Characteristics

Accessory Controller

## Permissible Overhung Load and Permissible Thrust Load

Unit = N

Features	Lineup	System Configuration	Product Line	Specifications and Characteristics	Permissible Overhung Load						Permissible Thrust Load				
					Distance from Shaft End mm										
					0	5	10	15	20						
Standard Type	28 mm	<b>AR24</b>	Gear Ratio	Permissible Overhung Load	25	34	52	—	—	1.5	2.2				
					35	44	58	85	—	4.6[6.1]*					
	42 mm	<b>AR46</b>			90	100	130	180	270	8.8[11.8]*	13.7[16.7]*				
					260	290	340	390	480	18[24]*					
	60 mm	<b>AR66</b>													
TH Geared Type	60 mm	<b>AR69</b>													
	85 mm	<b>AR98</b>													
	28 mm	<b>AR24</b>	7.2, 10, 20, 30		15	17	20	23	—	10					
PS Geared Type	42 mm	<b>AR46</b>			10	14	20	30	—	15					
					70	80	100	120	150	40					
	60 mm	<b>AR66</b>			220	250	300	350	400	100					
PN Geared Type	28 mm	<b>AR24</b>	5, 7.2, 10		45	60	80	100	—	20					
					100	120	150	190	—	100					
	42 mm	<b>AR46</b>			5	200	220	250	280	320					
					250	270	300	340	390						
	60 mm	<b>AR66</b>			330	360	400	450	520						
Harmonic Geared Type	90 mm	<b>AR98</b>			5, 7.2, 10	480	540	600	680	790	300				
					25	850	940	1050	1190	1380					
	30 mm	<b>AR24</b>	5, 7.2, 10		36	930	1030	1150	1310	1520					
					50	1050	1160	1300	1480	1710					
	42 mm	<b>AR46</b>			45	60	80	100	—	20					
					100	120	150	190	—						
PN Geared Type	60 mm	<b>AR66</b>			5	200	220	250	280	320					
					250	270	300	340	390						
	90 mm	<b>AR98</b>			330	360	400	450	520						
					5	480	520	550	580	620					
Harmonic Geared Type	30 mm	<b>AR24</b>	50, 100		7.2, 10	480	540	600	680	790	300				
					25	850	940	1050	1110	1190					
	42 mm	<b>AR46</b>			36	930	1030	1150	1220	1300					
					50	1050	1160	1300	1380	1490					
	60 mm	<b>AR66</b>			100	135	175	250	—	140					
					180	220	270	360	510	220					
Harmonic Geared Type	90 mm	<b>AR98</b>			320	370	440	550	720	450					
					1090	1150	1230	1310	1410	1300					
	30 mm	<b>AR24</b>													
	42 mm	<b>AR46</b>													
	60 mm	<b>AR66</b>													
Harmonic Geared Type	90 mm	<b>AR98</b>													

\*The brackets [ ] indicate the value for the electromagnetic brake type.

**Note**

With a double shaft product, the output shaft located on the opposite side of the motor output shaft is used to install a slit disk or similar device. Do not apply any load torque, overhung load or thrust load on this output shaft.

How to Read  
Specifications and  
Characteristics

Accessory  
Controller

Features  
Lineup  
System Configuration  
Product Line  
Specifications and Characteristics

Dimension  
Connection and Operation  
Combination List

Extended Functions


## Dimensions (Unit = mm)

● Motor

◇ Standard Type


Frame Size 28 mm

Product Name		Motor Product Name	L1	L2	Mass kg	CAD
Built-in Controller	Pulse Input					
<b>AR24SAKD-◇</b>	<b>AR24SAK-◇</b>	ARM24SAK	45	—	0.15	B705
<b>AR24SBKD-◇</b>	<b>AR24SBK-◇</b>			56		
<b>AR26SAKD-◇</b>	<b>AR26SAK-◇</b>	ARM26SAK	65	—	0.22	B706
<b>AR26SBKD-◇</b>	<b>AR26SBK-◇</b>			76		




Frame Size 42 mm

Product Name		Motor Product Name	Mass kg	CAD
Built-in Controller	Pulse Input			
<b>AR46SAKD-◇</b>	<b>AR46SAK-◇</b>	ARM46SAK	0.44	B718
<b>AR46SBKD-◇</b>	<b>AR46SBK-◇</b>			



Frame Size 60 mm

Product Name		Motor Product Name	L1	L2	Mass kg	CAD
Built-in Controller	Pulse Input					
<b>AR66SAKD-◇</b>	<b>AR66SAK-◇</b>	ARM66SAK	64	—	0.87	B719
<b>AR66SBKD-◇</b>	<b>AR66SBK-◇</b>			85.5		
<b>AR69SAKD-◇</b>	<b>AR69SAK-◇</b>	ARM69SAK	89.5	—	1.37	B720
<b>AR69SBKD-◇</b>	<b>AR69SBK-◇</b>			111		



● A number indicating the desired length of 1 (1 m), 2 (2 m) or 3 (3 m) for the cable included with the product is entered where the box ◇ is located within the product name.

● These dimensions are for double shaft models. For single shaft models, ignore the shaded orange areas.

Features

Lineup

System Configuration

Product Line

Specifications and Characteristics

Dimension

Connection and Operation

Combination List

Extended Functions


How to Read Specifications and Characteristics

Accessory

Controller

## Frame Size 85 mm


Product Name		Motor Product Name	Mass kg	CAD
Built-in Controller	Pulse Input			
<b>AR98SAKD-◇</b>	<b>AR98SAK-◇</b>	ARM98SAK	1.85	B721
<b>AR98SBKD-◇</b>	<b>AR98SBK-◇</b>	ARM98SBK		



## ◇Standard Type with Electromagnetic Brake


### Frame Size 42 mm

Product Name		Motor Product Name	Mass kg	CAD
Built-in Controller	Pulse Input			
<b>AR46SMKD-◇</b>	<b>AR46SMK-◇</b>	ARM46SMK	0.57	B722



### Frame Size 60 mm

Product Name		Motor Product Name	L	Mass kg	CAD
Built-in Controller	Pulse Input				
<b>AR66SMKD-◇</b>	<b>AR66SMK-◇</b>	ARM66SMK	99	1.13	B723
<b>AR69SMKD-◇</b>	<b>AR69SMK-◇</b>	ARM69SMK	124.5	1.63	B724




● A number indicating the desired length of **1** (1 m), **2** (2 m) or **3** (3 m) for the cable included with the product is entered where the box ◇ is located within the product name.

● The dimensions of the standard type frame size 85 mm are for double shaft models. For single shaft models, ignore the shaded orange areas.

Features	Lineup	System Configuration	Product Line	Specifications and Characteristics	Dimension	Connection and Operation	Combination List	Extended Functions	How to Read Specifications and Characteristics	Accessory	Controller


### Frame Size 85 mm

Product Name		Motor Product Name	Mass kg	CAD
Built-in Controller	Pulse Input	ARM98SMK	2.3	B725
<b>AR98SMKD-◇</b>				




### ◇TH Geared Type Frame Size 28 mm

Product Name		Motor Product Name	Gear Ratio	Mass kg	CAD
Built-in Controller	Pulse Input	ARM24SAK-T■	<b>7.2, 10, 20, 30</b>	0.21	B707
<b>AR24SAKD-T■-◇</b>					



### Frame Size 42 mm

Product Name		Motor Product Name	Gear Ratio	Mass kg	CAD
Built-in Controller	Pulse Input	ARM46SAK-T■	<b>3.6, 7.2, 10, 20, 30</b>	0.59	B726
<b>AR46SAKD-T■-◇</b>					




● A number indicating the gear ratio is entered where the box ■ is located within the product name.

● A number indicating the desired length of 1 (1 m), 2 (2 m) or 3 (3 m) for the cable included with the product is entered where the box ◇ is located within the product name.


## Frame Size 60 mm

Product Name		Motor Product Name	Gear Ratio	Mass kg	CAD
Built-in Controller	Pulse Input	ARM66SAK-T■	<b>3.6, 7.2, 10, 20, 30</b>	1.27	B727
<b>AR66SAKD-T■-◇</b>	<b>AR66SAK-T■-◇</b>				



## Frame Size 90 mm


Product Name		Motor Product Name	Gear Ratio	Mass kg	CAD
Built-in Controller	Pulse Input	ARM98SAK-T■	<b>3.6, 7.2, 10, 20, 30</b>	3	B728
<b>AR98SAKD-T■-◇</b>	<b>AR98SAK-T■-◇</b>				



## ◇TH Geared Type with Electromagnetic Brake

### Frame Size 42 mm

Product Name		Motor Product Name	Gear Ratio	Mass kg	CAD
Built-in Controller	Pulse Input	ARM46SMK-T■	<b>3.6, 7.2, 10, 20, 30</b>	0.72	B729
<b>AR46SMKD-T■-◇</b>	<b>AR46SMK-T■-◇</b>				




● A number indicating the gear ratio is entered where the box ■ is located within the product name.

● A number indicating the desired length of 1 (1 m), 2 (2 m) or 3 (3 m) for the cable included with the product is entered where the box ◇ is located within the product name.

Features	Lineup	System Configuration	Product Line	Specifications and Characteristics	Dimension	Connection and Operation	Combination List	Extended Functions	How to Read Specifications and Characteristics	Accessory	Controller


## Frame Size 60 mm

Product Name	Motor Product Name	Gear Ratio	Mass kg	CAD
Built-in Controller	Pulse Input			
<b>AR66SMKD-T■-◇</b>	<b>AR66SMK-T■-◇</b>	<b>3.6, 7.2, 10, 20, 30</b>	1.53	B730



## Frame Size 90 mm


Product Name	Motor Product Name	Gear Ratio	Mass kg	CAD
Built-in Controller	Pulse Input			
<b>AR98SMKD-T■-◇</b>	<b>AR98SMK-T■-◇</b>	<b>3.6, 7.2, 10, 20, 30</b>	3.5	B731



## ◇ PS Geared Type

### Frame Size 28 mm

Product Name	Motor Product Name	Gear Ratio	Mass kg	CAD
Built-in Controller	Pulse Input			
<b>AR24SAKD-PS■-◇</b>	<b>AR24SAK-PS■-◇</b>	<b>5, 7.2, 10</b>	0.25	B708



● A number indicating the gear ratio is entered where the box ■ is located within the product name.

● A number indicating the desired length of 1 (1 m), 2 (2 m) or 3 (3 m) for the cable included with the product is entered where the box ◇ is located within the product name.

Features

Lineup

System Configuration

Product Line

Specifications and Characteristics

Dimension

Connection and Operation

Combination List

Extended Functions


How to Read Specifications and Characteristics

Accessory

Controller


### Frame Size 42 mm

Product Name		Motor Product Name	Gear Ratio	L	Mass kg	CAD
Built-in Controller	Pulse Input					
<b>AR46SAKD-PS■-◇</b>	<b>AR46SAK-PS■-◇</b>	ARM46SAK-PS■	<b>5, 7.2, 10</b>	95.5	0.64	B742
			<b>25, 36, 50</b>	119	0.79	B743




### Frame Size 60 mm

Product Name		Motor Product Name	Gear Ratio	L	Mass kg	CAD
Built-in Controller	Pulse Input					
<b>AR66SAKD-PS■-◇</b>	<b>AR66SAK-PS■-◇</b>	ARM66SAK-PS■	<b>5, 7.2, 10</b>	96.5	1.27	B744
			<b>25, 36, 50</b>	116.5	1.57	B745



### Frame Size 90 mm

Product Name		Motor Product Name	Gear Ratio	L	Mass kg	CAD
Built-in Controller	Pulse Input					
<b>AR98SAKD-PS■-◇</b>	<b>AR98SAK-PS■-◇</b>	ARM98SAK-PS■	<b>5, 7.2, 10</b>	126.5	3.2	B746
			<b>25, 36, 50</b>	154	4	B747



● A number indicating the gear ratio is entered where the box ■ is located within the product name.

● A number indicating the desired length of 1 (1 m), 2 (2 m) or 3 (3 m) for the cable included with the product is entered where the box ◇ is located within the product name.

Features	Lineup	System Configuration	Product Line	Specifications and Characteristics	Dimension	Connection and Operation	Combination List	Extended Functions	How to Read Specifications and Characteristics	Accessory	Controller

#### ◆ **PS** Geared Type with Electromagnetic Brake

Frame Size 42 mm

Product Name		Motor Product Name	Gear Ratio	L	Mass kg	CAD
Built-in Controller	Pulse Input	ARM46SMK-PS■	5, 7.2, 10	125	0.77	B748
AR46SMKD-PS■-◇	AR46SMK-PS■-◇		25, 36, 50	148.5	0.92	B749

Features

## Lineup

System Configuration

Product Line

## Specifications and


## Dimension

Connection  
and Operation

Combination


Extended Functions

How to Read




Frame Size 60 mm

Product Name		Motor Product Name	Gear Ratio	L	Mass kg	CAD
Built-in Controller	Pulse Input					
AR66SMKD-PS■-◇	AR66SMK-PS■-◇	ARM66SMK-PS■	<b>5, 7.2, 10</b>	131.5	1.53	B750
			<b>25, 36, 50</b>	151.5	1.83	B751



Frame Size 90 mm

Product Name		Motor Product Name	Gear Ratio	L	Mass kg	CAD
Built-in Controller	Pulse Input					
AR98SMKD-PS■-◇	AR98SMK-PS■-◇	ARM98SMK-PS■	<b>5, 7.2, 10</b>	168.5	3.7	B752
			<b>25 36 50</b>	196	4.5	B753



A number indicating the gear ratio is entered where the box  is located within the product name.


● A number indicating the gear ratio is entered where the box  is located within the product name.  
● A number indicating the desired length of **1** (1 m), **2** (2 m) or **3** (3 m) for the cable included with the product is entered where the box  is located within the product name.

Features	Lineup	System Configuration	Product Line	Specifications and Characteristics	Dimension	Connection and Operation	Combination List	Extended Functions	How to Read Specifications and Characteristics	Accessory	Controller
----------	--------	----------------------	--------------	------------------------------------	-----------	--------------------------	------------------	--------------------	--	-----------	------------

## ◆ PN Geared Type


Frame Size 28 mm

Product Name		Motor Product Name	Gear Ratio	Mass kg	CAD
Built-in Controller	Pulse Input				
<b>AR24SAKD-N■-◇</b>	<b>AR24SAK-N■-◇</b>	ARM24SAK-N■	<b>5, 7.2, 10</b>	0.28	B709




Frame Size 42 mm

Product Name		Motor Product Name	Gear Ratio	Mass kg	CAD
Built-in Controller	Pulse Input				
<b>AR46SAKD-N■-◇</b>	<b>AR46SAK-N■-◇</b>	ARM46SAK-N■	<b>5, 7.2, 10</b>	0.7	B732



Frame Size 60 mm

Product Name		Motor Product Name	Gear Ratio	L	Mass kg	CAD
Built-in Controller	Pulse Input					
AR66SAKD-N■-◇	AR66SAK-N■-◇	ARM66SAK-N■	<b>5, 7.2, 10</b>	108.5	1.47	B733
			<b>25, 36, 50</b>	124.5	1.7	B734




A number indicating the gear ratio is entered where the box  is located within the product name.

● A number indicating the gear ratio is entered where the box ■ is located within the product name.

## Frame Size 90 mm


Product Name		Motor Product Name	Gear Ratio	L	Mass kg	CAD
Built-in Controller	Pulse Input	ARM98SAK-N■	5, 7.2, 10 25, 36, 50	139.5 162.5	3.7 4.4	B735 B736



## ◇ PN Geared Type with Electromagnetic Brake


### Frame Size 42 mm

Product Name		Motor Product Name	Gear Ratio	Mass kg	CAD
Built-in Controller	Pulse Input	ARM46SMK-N■	5, 7.2, 10	0.83	B737



## Frame Size 60 mm

Product Name		Motor Product Name	Gear Ratio	L	Mass kg	CAD
Built-in Controller	Pulse Input	ARM66SMK-N■	5, 7.2, 10 25, 36, 50	143.5 159.5	1.73 1.96	B738 B739



● A number indicating the gear ratio is entered where the box ■ is located within the product name.

● A number indicating the desired length of 1 (1 m), 2 (2 m) or 3 (3 m) for the cable included with the product is entered where the box ◇ is located within the product name.

Features

Lineup

System Configuration

Product Line

Specifications and Characteristics

Dimension

Connection and Operation

Combination List

Extended Functions


How to Read Specifications and Characteristics

Accessory

Controller

## Frame Size 90 mm


Product Name		Motor Product Name	Gear Ratio	L	Mass kg	CAD
Built-in Controller	Pulse Input					
<b>AR98SMKD-N■-◇</b>	<b>AR98SMK-N■-◇</b>	ARM98SMK-N■	<b>5, 7.2, 10</b> <b>25, 36, 50</b>	181.5 204.5	4.2 4.9	B740 B741



## ◇Harmonic Geared Type

### Frame Size 30 mm

Product Name		Motor Product Name	Gear Ratio	Mass kg	CAD
Built-in Controller	Pulse Input				
<b>AR24SAKD-H■-◇</b>	<b>AR24SAK-H■-◇</b>	ARM24SAK-H■	<b>50, 100</b>	0.24	B710



\*The position of the output shaft relative to the screw holes on the rotating part is arbitrary.


● A number indicating the gear ratio is entered where the box ■ is located within the product name.

● A number indicating the desired length of 1 (1 m), 2 (2 m) or 3 (3 m) for the cable included with the product is entered where the box ◇ is located within the product name.

Features	Lineup	System Configuration	Product Line	Specifications and Characteristics	Dimension	Connection and Operation	Combination List	Extended Functions	How to Read Specifications and Characteristics	Accessory	Controller

## Frame Size 42 mm


Product Name	Motor Product Name	Gear Ratio	Mass kg	CAD
Built-in Controller	Pulse Input			
<b>AR46SAKD-H■-◇</b>	<b>AR46SAK-H■-◇</b>	<b>ARM46SAK-H■</b>	<b>50, 100</b>	0.65 B754



\*The position of the output shaft relative to the screw holes on the rotating part is arbitrary.

## Frame Size 60 mm

Product Name	Motor Product Name	Gear Ratio	Mass kg	CAD
Built-in Controller	Pulse Input			
<b>AR66SAKD-H■-◇</b>	<b>AR66SAK-H■-◇</b>	<b>ARM66SAK-H■</b>	<b>50, 100</b>	1.38 B755



\*The position of the output shaft relative to the screw holes on the rotating part is arbitrary.

How to Read  
Specifications and  
Characteristics


Accessory

Controller

- A number indicating the gear ratio is entered where the box ■ is located within the product name.
- A number indicating the desired length of 1 (1 m), 2 (2 m) or 3 (3 m) for the cable included with the product is entered where the box ◇ is located within the product name.

Frame Size 90 mm


Product Name		Motor Product Name	Gear Ratio	Mass kg	CAD
Built-in Controller	Pulse Input				
<b>AR98SAKD-H■-◇</b>	<b>AR98SAK-H■-◇</b>	ARM98SAK-H■	<b>50, 100</b>	3.9	B756



#### ◆ Harmonic Geared Type with Electromagnetic Brake

Frame Size 42 mm

Product Name		Motor Product Name	Gear Ratio	Mass kg	CAD
Built-in Controller	Pulse Input				
<b>AR46SMKD-H■-◇</b>	<b>AR46SMK-H■-◇</b>	ARM46SMK-H■	<b>50, 100</b>	0.78	B757




\*The position of the output shaft relative to the screw holes on the rotating part is arbitrary.

- A number indicating the gear ratio is entered where the box ■ is located within the product name.
  - A number indicating the desired length of **1** (1 m), **2** (2 m) or **3** (3 m) for the cable included with the product is entered where the box ◇ is located within the product name.

## Frame Size 60 mm


Product Name		Motor Product Name	Gear Ratio	Mass kg	CAD
Built-in Controller	Pulse Input	ARM66SMK-H■	50, 100	1.64	B758
<b>AR66SMKD-H■-◇</b>	<b>AR66SMK-H■-◇</b>				



\*The position of the output shaft relative to the screw holes on the rotating part is arbitrary.

## Frame Size 90 mm

Product Name		Motor Product Name	Gear Ratio	Mass kg	CAD
Built-in Controller	Pulse Input	ARM98SMK-H■	50, 100	4.4	B759
<b>AR98SMKD-H■-◇</b>	<b>AR98SMK-H■-◇</b>				



● A number indicating the gear ratio is entered where the box ■ is located within the product name.  
 ● A number indicating the desired length of 1 (1 m), 2 (2 m) or 3 (3 m) for the cable included with the product is entered where the box ◇ is located within the product name.

Features

Lineup

System Configuration

Product Line

Specifications and Characteristics

Dimension

Connection and Operation

Combination List

Extended Functions

How to Read Specifications and Characteristics

Accessory


Controller

## ● Cables for Motor (Included), Cables for Electromagnetic Brake (Included)

Common to All Types


### • Cable for Motor

Cable Type	Length L (m)
Cable for Motor 1 m	1
Cable for Motor 2 m	2
Cable for Motor 3 m	3



### • Cables for Electromagnetic Brake (Electromagnetic brake type only)


Cable Type	Length L (m)
Cable for Electromagnetic Brake 1 m	1
Cable for Electromagnetic Brake 2 m	2
Cable for Electromagnetic Brake 3 m	3



## ● Driver

### Built-in Controller Type

Mass: 0.17 kg [CAD](#) B711




### Included

- Power Input Terminal Connector (CN1)  
Connector: MC1,5/5-STF-3,5 (PHOENIX CONTACT Inc.)
- Sensor Signal Connector (CN5)  
Connector: FK-MC0,5/5-ST-2,5 (PHOENIX CONTACT Inc.)
- Input Signal Connector (CN8)  
Connector: FK-MC0,5/9-ST-2,5 (PHOENIX CONTACT Inc.)
- Output Signal Connector (CN9)  
Connector: FK-MC0,5/7-ST-2,5 (PHOENIX CONTACT Inc.)

### Pulse Input Type

Mass: 0.17 kg [CAD](#) B546



### Included

- Control I/O Signal Connector (CN5)  
Case: 10336-52A0-008 (SUMITOMO 3M)  
Connector: 10136-3000PE (SUMITOMO 3M)
- Power Supply Input and Frame Ground Terminal Connector (CN1)  
Connector: MC1,5/3-STF-3,5 (PHOENIX CONTACT Inc.)

Features

Lineup

System Configuration

Product Line

Specifications and Characteristics

Dimension

Connection and Operation

Combination List

Extended Functions


How to Read Specifications and Characteristics

Accessory


Controller

## ■ Connection and Operation (Built-in controller type)

### ● Names and Functions of Driver Parts



[Driver Top]



### ① Signal Monitor Display

#### ◇ LED Indicator

Indication	Color	Function	Lighting Condition
POWER	Green	Power Supply Indication	When the power supply is input
ALARM	Red	Alarm Indication	Blinks when protective functions are activated.
C-DAT	Green	Communication Indication	When communication data is being exchanged
C-ERR	Red	Communication Error Indication	When communication data is in error

### ② Controller Setting Switch (SW1)

Indication	Function
SW1	Set this when you are using RS-485 communication. Set the controller number (Factory Setting: 0).

### ③ Baud Rate Switch (SW2)

Indication	Function
SW2	Set this when you are using RS-485 communication. Set the baud rate (Factory Setting: 7).

#### ◇ RS-485 Baud Rate Setting

No.	Baud Rate (bps)
0	9600
1	19200
2	38400
3	57600
4	115200
5~6	Not used
7	625000 (Connection with a network converter)
8~F	Not used

Features

Lineup

System Configuration

Product Line

Specifications and Characteristics

Dimension

Connection and Operation

Combination List

Extended Functions

How to Read Specifications and Characteristics

Accessory

Controller

#### 4 Function Switch (SW3)

Indication	No.	Function
SW3	1	Set the controller number (Factory Setting: 0) in combination with Controller Setting Switch (SW1).
	2	Set the RS-485 protocol (Factory Setting: OFF).
	3	Not used.
	4	Set the RS-485 termination ( $120\Omega$ ) (Factory Setting: OFF). OFF: Termination disabled ON: Termination enabled

#### ◇RS-485 Protocol Setting

Destination No.	Connection with a network converter	Modbus RTU Mode
2	OFF	ON

#### 5 I/O Signal Connector (CN8)

Indication	Pin No.	Signal Name	Initial Value	
CN8	1	IN0	HOME	Executes a return-to-home operation.
	2	IN1	START	Executes a positioning operation.
	3	IN2	M0	
	4	IN3	M1	Use these three bits to select the operation data No.
	5	IN4	M2	
	6	IN5	FREE	Stop motor excitation and release the electromagnetic brake.
	7	IN6	STOP	Stops the motor.
	8	IN7	ALM-RST	Resets the current alarm.

● Assign functions by setting parameters. Initial values are shown above. For details, refer to the user's manual.

The following input signals can be assigned to input terminals IN0 to 7.

Input Signal				
0: Not used	8: MS0	18: STOP	36:R4	45:R13
1:FWD	9:MS1	24:ALM-RST	37:R5	46:R14
2:RVS	10:MS2	25:P-PRESET	38:R6	47:R15
3:HOME	11:MS3	26:P-CLR	39:R7	48:M0
4:START	12:MS4	27:HMI	40:R8	49:M1
5:SSTART	13:MS5	32:R0	41:R9	50:M2
6:+JOG	16:FREE	33:R1	42:R10	51:M3
7:-JOG	17:C-ON	34:R2	43:R11	52:M4
		35:R3	44:R12	53:M5

#### 6 Output Signal Connector (CN9)

Indication	Pin No.	Signal Name	Initial Value	
CN9	1	OUT0	HOME-P	This signal is output when the motor is at the home position.
	2	OUT1	END	This signal is output when the positioning operation is complete.
	3	OUT2	AREA1	This signal is output when the motor is in area 1.
	4	OUT3	READY	This signal is output when the driver is ready.
	5	OUT4	WNG	This output signal indicates the driver warning status.
	6	OUT5	ALM	This output signal indicates the driver alarm status (normally closed).

● Assign functions by setting parameters. Initial values are shown above. For details, refer to the user's manual.

The following output signals can be assigned to output terminals OUT0 to 5.

Output Signal					
0: Not used	9:MS1_R	33:R1	42:R10	51:M3_R	67:READY
1:FWD_R	10:MS2_R	34:R2	43:R11	52:M4_R	68:MOVE
2:RVS_R	11:MS3_R	35:R3	44:R12	53:M5_R	69:END
3:HOME_R	12:MS4_R	36:R4	45:R13	60:+LS_R	70:HOME-P
4:START_R	13:MS5_R	37:R5	46:R14	61:-LS_R	71:TLC
5:SSTART_R	16:FREE_R	38:R6	47:R15	62:HOMES_R	72:TIM
6:+JOG_R	17:C-ON_R	39:R7	48:M0_R	63:SLIT_R	73:AREA1
7:-JOG_R	18:STOP_R	40:R8	49:M1_R	65:ALM	74:AREA2
8:MS0_R	32:R0	41:R9	50:M2_R	66:WNG	75:AREA3
					80:S-BSY


#### 7 Sensor Signal Input (CN5)

Indication	Pin No.	Signal Name	Initial Value	
CN5	1	+LS	+side limit sensor input	
	2	-LS	-side limit sensor input	
	3	HOMES	Mechanical home sensor input	
	4	SLIT	Slit Sensor Input	
	5	IN-COM2	Sensor common	


● Connection Diagram

- ◇ Connection to Programmable Controller
- Connecting to a Current Sink Output Circuit

Controller



Driver



Note

- Use 24 VDC input signals.
- Use 24 VDC output signals at 10 mA or less. When the current value exceeds 10 mA, connect the external resistor  $R_0$  to keep the current 10 mA or less.
- The maximum output signal saturation voltage is 3 V.
- Provide a distance of at least 200 mm between the signal lines and power lines (power supply lines, motor lines, etc.).  
Do not run the signal lines in the same duct as power lines or bundle them with power lines.
- If noise generated by the motor cable or power supply cable causes a problem with the specific wiring or layout, shield the cable or use ferrite cores.

Features

Lineup

System Configuration

Product Line

Specifications and Characteristics

Dimension and Operation

Combination List


Extended Functions

How to Read Specifications and Characteristics

Accessory

Controller


◇ Connection to Programmable Controller  
 • Connecting to a Current Source Output Circuit



Features	Lineup	System Configuration	Product Line	Specifications and Characteristics	Dimension	Connection and Operation	Combination List	Extended Functions	How to Read Specifications and Characteristics	Accessory	Controller
----------	--------	----------------------	--------------	------------------------------------	-----------	--------------------------	------------------	--------------------	--	-----------	------------

## ■ Connection and Operation (Pulse input type)

### ● Names and Functions of Driver Parts



#### ① Signal Monitor Display

##### ◇ LED Indicator

Indication	Color	Function	Lighting Condition
POWER	Green	Power Supply Indication	When the main power supply is input
ALARM	Red	Alarm Indication	Blinks when protective functions are activated.

#### ◇ Alarm Contents


Dimension	Blink Count	Function	Operating Condition
Connection and Operation	2	Overheat Protection	When the temperature inside the driver exceeds 85°C
		Overload	When the amount of time during which the load torque exceeded the maximum torque exceeds the overload detection time. (Default Value: 5 seconds)
	3	Overspeed	The motor output shaft speed exceeds 4500 r/min.
	3	Command Pulse Error	The command pulse value becomes abnormal.
Combination List	4	Overvoltage Protection	The primary voltage of the driver's inverter exceeds the upper limit.
		Undervoltage	The primary voltage of the driver's inverter drops below the lower limit.
	7	Excessive Positioning Deviation Error at Current On	The positioning deviation exceeds the overflow revolutions. (Default Value: 3 revolutions)
		Excessive Positioning Deviation Error at Current Off	The current is turned on even though the positioning deviation when the current is turned off was equal to or greater than the permissible value. (Default Value: 100 revolutions or more)
Extended Functions	8	Operation Data Error	Return to electrical home operation is performed while an operation data error warning is present.
		Electronic Gear Setting Error	The resolution set by the electronic gear is outside the specified range.
	9	Sensor Error during Operation	A sensor error occurs while the motor is rotating.
		Initial Sensor Error	The power source is turned on when the motor cable is not connected to the driver.
How to Read Specifications and Characteristics	8	Initial Rotor Revolution Error	The main power supply is turned on while the motor is rotating.
		Motor Combination Error	A motor not supported by the driver is connected.
Accessory	9	EEPROM Error	A motor control parameter is damaged.

#### ② Current Setting Switch

Indication	Switch Name	Function
CURRENT	Current Setting Switch	This switch adjusts the operating current. It is used to limit the torque and temperature rise. A desired current can be set as a percentage (%) of the rated output power current. Factory Setting: F

#### ③ Velocity Filter Setting Switch

Indication	Switch Name	Function
V-FIL	Velocity Filter Setting Switch	This switch adjusts the motor response. Adjust the switch if you want to suppress motor vibration or cause the motor to start/stop smoothly. "0" and "F" correspond to the minimum and maximum velocity filter settings, respectively. Factory Setting: 1



Features

Lineup

System Configuration

Product Line

Characteristics

Dimension

Connection and Operation

Combination List

Extended Functions

How to Read Specifications and Characteristics

Accessory

Controller

#### 4 Function Select/Setting Switch (SW1)

Indication	Switch Name	Function
4	Resolution Select Switch D0/D1 CS0/CS1	These switches are used to set the resolution per rotation of the motor output shaft. 4: OFF, 3: OFF → 1000 pulses (0.36°/step) [Factory setting] 4: OFF, 3: ON → 10000 pulses (0.036°/step) 4: ON, 3: OFF → 500 pulses (0.72°/step) 4: ON, 3: ON → 5000 pulses (0.072°/step)
2	Control Modes Select Switch NORM/CCM	This switch toggles the driver between the normal mode and current control mode. In the current control mode, noise and vibration can be reduced although the motor synchronicity may reduce. OFF: Normal Mode [Factory setting] ON: Current Control Mode
1	Pulse Input Mode Select Switch 2P/1P	This switch toggles the pulse input mode between 1-pulse input mode and 2-pulse input mode. OFF: 2-Pulse Input Mode [Factory setting] ON: 1-Pulse Input Mode


#### 5 I/O Signal Connector (CN5, 36 pins)

Indication	I/O	Pin No.	Code		Signal Name		Product Line	Specifications and Characteristics	Dimension	Connection and Operation
			Positioning Operation	Push-Motion Operation <sup>*1</sup>	Positioning Operation	Push-Motion Operation <sup>*1</sup>				
CN5	Output Power	-	1	-	-	-				
		2	GND		Ground connection					
		3	ASG+		A-Phase Pulse Output Signal (Line driver)					
		4	ASG-							
		5	BSG+		B-Phase Pulse Output Signal (Line driver)					
		6	BSG-							
		7	TIM1+		Timing Output (Line driver)					
		8	TIM1-							
		9	ALM+		Alarm Output					
		10	ALM-							
		11	WNG+		Warning Output					
		12	WNG-							
		13	END+		Positioning Completion Output					
		14	END-							
	Input	15	READY+/AL0+ <sup>*1</sup>		Operation Ready Complete Output/Alarm Code 0 Output <sup>*1</sup>					
		16	READY-/AL0- <sup>*1</sup>							
		17	TLC+/AL1+ <sup>*1</sup>		Torque Limiting Output/Alarm Code 1 Output <sup>*1</sup>					
		18	TLC-/AL1- <sup>*1</sup>							
		19	TIM2+/AL2+ <sup>*1</sup>		Timing Output (Open collector)/Alarm Code 2 Output <sup>*1</sup>					
		20	TIM2-/AL2- <sup>*1</sup>							
		21	GND		Ground connection					
		22	IN-COM		Input Signal Common					
		23	C-ON <sup>*2</sup>		Current On Input <sup>*2</sup>					
		24	CLR/ALM-RST		Deviation Counter Clear Input/Alarm Reset Input					
		25	CCM		Current Control Mode ON Input					
		26	CS	T-MODE <sup>*1</sup>	Resolution Select Input	Push-Motion Operation ON <sup>*1</sup>				
		27	-	M0 <sup>*1</sup>	-					
		28	RETURN	M1 <sup>*1</sup>	Return To Electrical Home Operation	Push-Current Setting Select Input <sup>*1</sup>				
		29	P-RESET	M2 <sup>*1</sup>	Position Reset Input					
		30	FREE		Excitation OFF					
		31	CW+/PLS+		CW Pulse Signal Input/Pulse Input (+5 V/line driver)					
		32	CW-/PLS-							
		33	CW+24/PLS+24V		CW Pulse Signal Input/Pulse Input (+24 V)					
		34	CCW+24/DIR+24V		CCW Pulse Signal Input/Rotation Direction Input (+24 V)					
		35	CCW+/DIR+		CCW Pulse Signal Input/Rotation Direction Input (+5 V/line driver)					
		36	CCW-/DIR-							


\*1 The signal will become effective if the applicable setting has been changed using the accessory control module **OPX-2A** or data setting software **MEXEO2** (both sold separately).

\*2 The factory setting of current ON input is normally open. When operating the motor, be sure to turn the current ON input "ON." If you are not using the current ON input, use the accessory control module **OPX-2A** or data setting software **MEXEO2** to set the input logic to normally closed.

Features	Lineup	System Configuration	Product Line	Specifications and Characteristics	Dimension	Connection and Operation	Combination List	Extended Functions	How to Read Specifications and Characteristics	Accessory	Controller
----------	--------	----------------------	--------------	------------------------------------	-----------	--------------------------	------------------	--------------------	--	-----------	------------



When pulse input is of 24 V type




Note

- Use 30 VDC or less for the output signals. When the current value exceeds 10 mA, connect the external resistor  $R_o$ .
  - Connect a termination resistor of  $100\ \Omega$  or more between the line receiver inputs.
  - Use multi-core, twisted-pair shielded wires of AWG 28~24 ( $0.08\sim0.2\ mm^2$ ) for the I/O signal lines (CNS), and keep wiring as short as possible (within 2 m).
  - Note that as the length of the pulse signal line increases, the maximum transmission frequency decreases.
  - Provide a distance of 200 mm min. between the I/O signal lines and power lines (AC lines, motor lines and other large-current circuits).


## ◇ Connection to Programmable Controller

### • Connecting to a Current Source Output Circuit


When pulse input is of line driver type



When pulse input is of 5 V type



When pulse input is of 24 V type



#### Note

- Use 30 VDC or less for the output signals. When the current value exceeds 10 mA, connect the external resistor  $R_o$ .
- Connect a termination resistor of 100 Ω or more between the line receiver inputs.
- Use multi-core, twisted-pair shielded wires of AWG 28~24 (0.08~0.2 mm<sup>2</sup>) for the I/O signal lines (CN5), and keep wiring as short as possible (within 2 m).
- Note that as the length of the pulse signal line increases, the maximum transmission frequency decreases.
- Provide a distance of 200 mm min. between the I/O signal lines and power lines (AC lines, motor lines and other large-current circuits).

Features

Lineup

System Configuration

Product Line

Specifications and Characteristics

Dimension

Connection and Operation

Combination List

Extended Functions

How to Read Specifications and Characteristics

Accessory Controller

## Motor and Driver Combinations

Product names for motor and driver combinations are shown below.

Features	Lineup	System Configuration	Product Line	Specifications and Characteristics	Type	Built-in Controller Type		Pulse Input Type		
					Product Name	Motor Product Name	Driver Product Name	Product Name	Motor Product Name	Driver Product Name
Standard Type	TH Geared Type	PS Geared Type	PN Geared Type	Harmonic Geared Type	<b>AR24S</b> □KD-◇*1	ARM24S□K		<b>AR24S</b> □K-◇*1	ARM24S□K	
					<b>AR26S</b> □KD-◇*1	ARM26S□K		<b>AR26S</b> □K-◇*1	ARM26S□K	
					<b>AR46S</b> □KD-◇*2	ARM46S□K		<b>AR46S</b> □K-◇*2	ARM46S□K	
					<b>AR66S</b> □KD-◇*2	ARM66S□K		<b>AR66S</b> □K-◇*2	ARM66S□K	
					<b>AR69S</b> □KD-◇*2	ARM69S□K		<b>AR69S</b> □K-◇*2	ARM69S□K	
					<b>AR98S</b> □KD-◇*2	ARM98S□K		<b>AR98S</b> □K-◇*2	ARM98S□K	
	TH Geared Type	PS Geared Type	PN Geared Type	Harmonic Geared Type	<b>AR24SAKD-T</b> ■-◇	ARM24SAK-T■		<b>AR24SAK-T</b> ■-◇	ARM24SAK-T■	
					<b>AR46S</b> □KD-T■-◇	ARM46S□K-T■		<b>AR46S</b> □K-T■-◇	ARM46S□K-T■	
					<b>AR66S</b> □KD-T■-◇	ARM66S□K-T■		<b>AR66S</b> □K-T■-◇	ARM66S□K-T■	
					<b>AR98S</b> □KD-T■-◇	ARM98S□K-T■		<b>AR98S</b> □K-T■-◇	ARM98S□K-T■	
					<b>AR24SAKD-PS</b> ■-◇	ARM24SAK-PS■		<b>AR24SAK-PS</b> ■-◇	ARM24SAK-PS■	
ARD-KD	TH Geared Type	PS Geared Type	PN Geared Type	Harmonic Geared Type	<b>AR46S</b> □KD-PS■-◇	ARM46S□K-PS■		<b>AR46S</b> □K-PS■-◇	ARM46S□K-PS■	
					<b>AR66S</b> □KD-PS■-◇	ARM66S□K-PS■		<b>AR66S</b> □K-PS■-◇	ARM66S□K-PS■	
					<b>AR98S</b> □KD-PS■-◇	ARM98S□K-PS■		<b>AR98S</b> □K-PS■-◇	ARM98S□K-PS■	
					<b>AR24SAKD-N</b> ■-◇	ARM24SAK-N■		<b>AR24SAK-N</b> ■-◇	ARM24SAK-N■	
					<b>AR46S</b> □KD-N■-◇	ARM46S□K-N■		<b>AR46S</b> □K-N■-◇	ARM46S□K-N■	
	PN Geared Type	Harmonic Geared Type	Harmonic Geared Type	Harmonic Geared Type	<b>AR66S</b> □KD-N■-◇	ARM66S□K-N■		<b>AR66S</b> □K-N■-◇	ARM66S□K-N■	
					<b>AR98S</b> □KD-N■-◇	ARM98S□K-N■		<b>AR98S</b> □K-N■-◇	ARM98S□K-N■	
					<b>AR24SAKD-H</b> ■-◇	ARM24SAK-H■		<b>AR24SAK-H</b> ■-◇	ARM24SAK-H■	
					<b>AR46S</b> □KD-H■-◇	ARM46S□K-H■		<b>AR46S</b> □K-H■-◇	ARM46S□K-H■	
					<b>AR66S</b> □KD-H■-◇	ARM66S□K-H■		<b>AR66S</b> □K-H■-◇	ARM66S□K-H■	
					<b>AR98S</b> □KD-H■-◇	ARM98S□K-H■		<b>AR98S</b> □K-H■-◇	ARM98S□K-H■	

\*1 Either **A** (single shaft) or **M** (electromagnetic brake) indicating the configuration is entered where the box □ is located within the product name.

A number indicating the gear ratio is entered where the box ■ is located within the product name.

A number indicating the desired length of **1** (1 m), **2** (2 m) or **3** (3 m) for the cable included with the product is entered where the box ◇ is located within the product name.

\*2 Either **A** (single shaft) or **B** (double shaft) indicating the motor shaft configuration is entered where the box □ is located within **AR24S**□K(D)-◇ and **AR26S**□K(D)-◇.

\*2 Either **A** (single shaft), **B** (double shaft), or **M** (electromagnetic brake) indicating the motor shaft configuration is entered where the box □ is located within **AR46S**□K(D)-◇, **AR66S**□K(D)-◇, **AR69S**□K(D)-◇, and **AR98S**□K(D)-◇.

ARD-K

Dimensions
Connection and Operation

Combination List
Extended Functions

How to Read Specifications and Characteristics
Accessory

Controller
------------

# Extended Functions

With the accessory control module **OPX-2A** or data setting software **MEXEO2**, extended functions of the **AR** Series are available. You can change the internal parameters of the driver, perform test operations and monitor the operation.

Control Module **OPX-2A**

→ Page 53



Data Setting Software **MEXEO2**

→ Page 54



## Parameter Settings (For pulse input type)

You can set the advanced settings of the signals and change the generation condition of the alarm.

Application Parameters	Running Current	Current value assigned to the operating current setting switch
	Velocity Filter	Filter time constant assigned to the speed filter setting switch
	I/O	Input signal mode Positioning operation/push-motion operation switching Alarm code signal enabled/disabled C-ON signal logic Output condition for END signal (output width) Current value applicable to push-motion operation
	Normal Mode	Standstill current in the normal mode Speed difference gain in the normal mode
	Current Control Mode	Position loop gain in the current control mode Speed loop gain in the current control mode Speed loop integral time constant in the current control mode Damping control enabled/disabled in the current control mode Damping control vibration frequency in the current control mode
	Alarm and Warning	Operation data error warning enabled/disabled Generation condition of excessive positioning deviation alarm at current on Generation condition of overflow rotation alarm during current off Generation condition of overload alarm Generation condition of excessive positioning deviation warning Generation condition of overvoltage warning Generation condition of undervoltage warning Generation condition of overheat warning Generation condition of overload warning Generation condition of overspeed warning
	Return To Electrical Home Operation	Operating speed for return to electrical home operation Acceleration/deceleration rate for return to electrical home operation Starting speed for return to electrical home operation
	Test Operation	Operating speed for test operation Acceleration/deceleration rate for test operation Starting speed for test operation
	Control Module	Speed monitor display Show the speed on the control module with a sign or as an absolute value Gear ratio for geared motor used for speed monitor
	Electronic Gear	Resolution assigned to each resolution select switch
System Parameters (Becomes effective after the power is cycled.)	Pulse Input Mode	
	Operation Setting	Smooth drive enabled/disabled Initial motor excitation position at power on Detected position/electrical angle 0° switching Automatic return operation at current ON enabled/disabled Motor rotation direction


## Monitor

You can monitor various signals, alarms and motor speeds/positions, and also perform test operations.

Monitor	Monitor positions
	Monitor speeds
	I/O Monitoring
Waveform Monitoring*	Monitor positions*
	Monitor speeds*
	Measure waveforms*
	Save waveforms*
Testing	Perform test operation (JOG operation)
	Monitor conditions during test operation
	Return To Electrical Home Operation
	Forcibly turn output signals ON/OFF
Alarm	Check content when generated
	Check alarm history (10 most recent alarms)
	Clear alarm history
	Release
Warning	Check content when generated
	Check alarm history (10 most recent alarms)
	Clear alarm history

### Waveform Monitoring

You can monitor various signals and motor speeds/positions using waveforms.



## Others

- Electrical home reset
- Parameter initialization

\*This function is available only when the data setting software (**MEXEO2**) is used.

Features	Lineup	System Configuration	Product Line	Specifications and Characteristics	Dimension	Connection and Operation	Combination List	Extended Functions	How to Read Specifications and Characteristics	Accessory	Controller

# How to Read Specifications Table

Features

Lineup

System Configuration

Product Line

Characteristics and

Dimension

Connection and Operation

Combination List

Extended Functions

How to Read Specifications and Characteristics

Accessory

Controller

Product Name	Built-in Controller	AR46S□KD-◇	AR46S□KD-N5-◇
Pulse Input		AR46S□K-◇	AR46S□K-N5-◇
① Maximum Holding Torque	N·m	0.3	1.35
② Rotor Inertial Moment	J: kg·m <sup>2</sup>	58×10 <sup>-7</sup> [73×10 <sup>-7</sup> ]*1	58×10 <sup>-7</sup> [73×10 <sup>-7</sup> ]*1
③ Gear Ratio		—	5
④ Resolution	When Set to 1000P/R	0.36°/Pulse	0.072°/Pulse
⑤ Permissible Torque	N·m	—	1.35
⑥ Maximum Torque	N·m	—	1.5
⑦ Holding Torque at Motor Standstill	While Power is Supplied N·m	0.15	0.75
	Electromagnetic Brake N·m	0.15	0.75
⑧ Permissible Speed Range	r/min	—	0~600
⑨ Backlash	arc minute (degrees)	—	2(0.034°)
⑩ Power Supply Input	Voltage	24 VDC±10% (24 VDC±5%)*2/48 VDC±5%	
	Input Current	A	1.4(1.8)*2
	Electromagnetic Brake*3	Power Supply Input	24 VDC±5%*4 0.08 A

\*1 The brackets [ ] indicate the specifications for the electromagnetic brake type.

\*2 The parentheses () indicate the specifications for the built-in controller type.

\*3 For the pulse input type, a separate power supply for the electromagnetic brake is also required.

\*4 If the wiring distance between the motor and driver is extended to 20 m or longer using an accessory cable (sold separately), the 24 VDC±4% specification applies.

## ① Maximum Holding Torque

The maximum holding torque (holding force) the motor has when power (rated current) is being supplied but the motor shaft is not rotating. (With geared types, the value of holding torque considers the permissible strength of the gear.)

## ② Rotor Inertial Moment

This refers to the inertia of rotor inside the motor. This is necessary when the required torque (acceleration torque) for the motor is calculated.

## ③ Gear Ratio

This is the ratio in rotation speed between the input speed from the motor and the speed of the gear output shaft. For example, the gear ratio 10 indicates the input speed from the motor is 10 r/min and the output gear shaft is 1 r/min.

## ④ Resolution

The resolution is the angular distance (in degrees) that the motor moves at the input of one pulse from the driver. It differs depending on the motor structure and excitation mode.

## ⑤ Permissible Torque

The permissible torque represents the maximum torque that can be applied continuously to the output gear shaft. For the types other than the **PS**, **PN** and harmonic geared types, the total torque including acceleration and deceleration torque should also not exceed the permissible torque.

## ⑥ Maximum Torque

(**PS** geared, **PN** geared and harmonic geared type only)

This is the max. torque that can be applied to the gear output shaft during acceleration/deceleration such as when an inertial load is started and stopped.

## ⑦ Holding Torque at Motor Standstill

While Power is Supplied: The holding torque when the automatic current cutback function is activated

Electromagnetic Brake: Static friction torque that the electromagnetic brake can generate when stopped (The electromagnetic brake is a power off activated type.)

## ⑧ Permissible Speed Range

This is the range for rotation on the gear output shaft.

## ⑨ Backlash


This is the play of the gear output shaft when the motor shaft is fixed. When positioning in bi-direction, the positioning accuracy is affected.

## ⑩ Power Supply Input

The current value of the power input is the max. input current value. (The input current varies according to the rotation speed.)

# How to Read Speed – Torque Characteristics

The characteristics diagram below is the characteristics that indicate the relationship between the speed and torque when a stepping motor is driven. The required speed and torque is always used when selecting a stepping motor. On the graph of characteristics, the horizontal axis expresses the speed at motor output shaft while the vertical axis expresses the torque.




## ① Max. Holding Torque

The maximum holding torque (holding force) the stepping motor has when power (rated current) is being supplied but the motor shaft is not rotating.

## ② Pullout Torque

The pullout torque is the maximum torque that can be output at a given speed. When selecting a motor, ensure that the required torque falls within this curve.

The following figure shows the speed – torque characteristics of **AR66SAK-◇**.




Depending on the driving conditions, a considerable amount of heat may be generated by the motor. Be sure to keep the temperature of the motor case at approximately 100°C.

# Accessory (Sold separately)

## Control Module (RoHS)

You can use these to set drivers' internal parameters and set and change data.

You can also use these to set speeds, monitor the I/O, and perform teaching.




### Product Line

Product Name
<b>OPX-2A</b>

### Dimensions (Unit = mm)


#### Control Module

Mass: 0.25kg [CAD](#) B453



#### Panel Cut-Out for Control Module

(Installation Plate Thickness 1~3 mm)



Features

Lineup

System Configuration

Product Line

Specifications and Characteristics

Dimension

Connection and Operation

Combination List

How to Read Specifications and Characteristics

Accessory

Controller

# Communication Cable for the Data Setting Software

(RoHS)

Features

Lineup

System Configuration

Product Line

Specifications and Characteristics

Dimension

Connection and Operation

Combination List

Extended Functions

How to Read Specifications and Characteristics

Accessory

Controller


This cable is required to connect the driver to the PC where the data setting software is installed.

## Product Line

Product Name
<b>CC05IF-USB</b>



## PC and Driver Connection



**Note**

To connect the driver to a PC, you must install a dedicated software driver in the PC.

## Data Setting Software MEXE02

The data setting software can be downloaded from our website. It is also available on CD-ROM.

For details, make a request on our website, or contact the nearest Oriental Motor sales office.

<http://www.orientalmotor.com.sg/>

## PC System Requirements

### Operating System (OS)

- Microsoft Windows 2000 Professional Service Pack 4  
Be sure to install Update Rollup 1 provided by Microsoft.  
To check whether Update Rollup 1 is installed, use "Add or Remove Programs."

Only the following 32-bit (x86) and 64-bit (x64) OS versions are supported.

- Microsoft Windows XP Home Edition Service Pack 3
- Microsoft Windows XP Professional Service Pack 2
- Microsoft Windows XP Professional Service Pack 3\*
- Microsoft Windows Vista Home Basic Service Pack 2
- Microsoft Windows Vista Home Premium Service Pack 2
- Microsoft Windows Vista Business Service Pack 2
- Microsoft Windows Vista Ultimate Service Pack 2
- Microsoft Windows Vista Enterprise Service Pack 2
- Microsoft Windows 7 Starter Service Pack 1
- Microsoft Windows 7 Home Premium Service Pack 1
- Microsoft Windows 7 Professional Service Pack 1
- Microsoft Windows 7 Ultimate Service Pack 1
- Microsoft Windows 7 Enterprise Service Pack 1

\*32-bit (x86) version only

### PC

Recommended CPU*1	Intel Core processor 2 GHz or higher (Must be compatible with the OS)
Display	Video Adapter and Monitor with Resolution of XGA (1024×768) min.
Recommended Memory*1	32-bit (x86) version: 1 GB or more 64-bit (x64) version: 2 GB or more
Hard Disk*2	Free disk space of 30 MB or more
USB Port	USB1.1 × 1 port
Disk Device	CD-ROM drive (for installing the software)

\*1 Must satisfy the operating requirements of the OS

\*2 MEXE02 requires Microsoft .NET Framework 2.0 Service Pack 2. When the service pack is not installed, it will automatically be installed. This will require up to 500 MB of additional free space on your PC.

**Note**

Depending on the system environment that you are using, the required memory and hard disk space may vary.

Windows and Windows Vista are registered trademarks of Microsoft Corporation in the United States and other countries.

# 1 Connection Cable Sets (RoHS), Flexible Connection Cable Sets (RoHS)

# 2 Extension Cable Sets (RoHS), Flexible Extension Cable Sets (RoHS)


The **AR** Series comes with a cable of 1 m, 2 m or 3 m for a connection between the motor and driver. When the distance between the motor and driver is extended to 3 m or longer, a connection cable set or extension cable set must be used. Use a flexible connection cable set or flexible extension cable set if the cable will be flexed repeatedly.

## System Configuration

### When Connecting the Motor and Driver without Using an Included Cable

Use a connection cable set.


Use a flexible connection cable set if the cable will be bent.



### When Extending the Distance between the Motor and the Driver Using an Included Cable

Use an extension cable set and connect it to the included cable.

Use a flexible extension cable added if the cable will be bent.



\*Cables for electromagnetic brake are for use when using electromagnetic brake type motors.

**Note**

Keep the overall cable length 30 m or less when using an extension cable set or a flexible extension cable set to connect with a cable included with the **AR** Series.

For the pulse input type, a separate power supply for electromagnetic brakes is also required.

Features	Lineup	System Configuration	Product Line	Specifications and Characteristics	Dimension	Connection and Operation	Combination List	Extended Functions	How to Read Specifications and Characteristics	Accessory	Controller
----------	--------	----------------------	--------------	------------------------------------	-----------	--------------------------	------------------	--------------------	--	-----------	------------

# 1 Connection Cable Sets (RoHS), Flexible Connection Cable Sets (RoHS)

## Product Line

### Connection Cable Sets

◇ For Standard Type Motor



Cable for Motor

Product Name	Length L (m)
<b>CC050VA2F2</b>	5
<b>CC070VA2F2</b>	7
<b>CC100VA2F2</b>	10
<b>CC150VA2F2</b>	15
<b>CC200VA2F2</b>	20
<b>CC300VA2F2</b>	30

### Flexible Connection Cable Sets

◇ For Standard Type Motor



Cable for Motor

Product Name	Length L(m)
<b>CC010VA2R2</b>	1
<b>CC020VA2R2</b>	2
<b>CC030VA2R2</b>	3
<b>CC050VA2R2</b>	5
<b>CC070VA2R2</b>	7
<b>CC100VA2R2</b>	10
<b>CC150VA2R2</b>	15
<b>CC200VA2R2</b>	20
<b>CC300VA2R2</b>	30

◇ For Electromagnetic Brake Type Motor



Cable for Motor

Product Name	Length L (m)
<b>CC050VA2FB2</b>	5
<b>CC070VA2FB2</b>	7
<b>CC100VA2FB2</b>	10
<b>CC150VA2FB2</b>	15
<b>CC200VA2FB2</b>	20
<b>CC300VA2FB2</b>	30

◇ For Electromagnetic Brake Type Motor



Cable for Motor

Product Name	Length L(m)
<b>CC010VA2RB2</b>	1
<b>CC020VA2RB2</b>	2
<b>CC030VA2RB2</b>	3
<b>CC050VA2RB2</b>	5
<b>CC070VA2RB2</b>	7
<b>CC100VA2RB2</b>	10
<b>CC150VA2RB2</b>	15
<b>CC200VA2RB2</b>	20
<b>CC300VA2RB2</b>	30

# 2 Extension Cable Sets (RoHS), Flexible Extension Cable Sets (RoHS)

### Extension Cable Sets

◇ For Standard Type Motor



Cable for Motor

Product Name	Length L(m)
<b>CC010VA2F2</b>	1
<b>CC020VA2F2</b>	2
<b>CC030VA2F2</b>	3
<b>CC050VA2F2</b>	5
<b>CC070VA2F2</b>	7
<b>CC100VA2F2</b>	10
<b>CC150VA2F2</b>	15
<b>CC200VA2F2</b>	20

### Flexible Extension Cable Sets

◇ For Standard Type Motor



Cable for Motor

Product Name	Length L(m)
<b>CC010VA2R2</b>	1
<b>CC020VA2R2</b>	2
<b>CC030VA2R2</b>	3
<b>CC050VA2R2</b>	5
<b>CC070VA2R2</b>	7
<b>CC100VA2R2</b>	10
<b>CC150VA2R2</b>	15
<b>CC200VA2R2</b>	20

◇ For Electromagnetic Brake Type Motor



Cable for Motor

Product Name	Length L(m)
<b>CC010VA2FBT2</b>	1
<b>CC020VA2FBT2</b>	2
<b>CC030VA2FBT2</b>	3
<b>CC050VA2FBT2</b>	5
<b>CC070VA2FBT2</b>	7
<b>CC100VA2FBT2</b>	10
<b>CC150VA2FBT2</b>	15
<b>CC200VA2FBT2</b>	20

◇ For Electromagnetic Brake Type Motor



Cable for Motor

Product Name	Length L(m)
<b>CC010VA2RBT2</b>	1
<b>CC020VA2RBT2</b>	2
<b>CC030VA2RBT2</b>	3
<b>CC050VA2RBT2</b>	5
<b>CC070VA2RBT2</b>	7
<b>CC100VA2RBT2</b>	10
<b>CC150VA2RBT2</b>	15
<b>CC200VA2RBT2</b>	20

Features

Lineup

System Configuration

Product Line

Specifications and Characteristics

Dimension

Connection and Operation

Extended Functions

How to Read Specifications and Characteristics

Accessory


Controller

56


## Dimension (Unit = mm)

### ● Connection Cable

#### ◇ Cable for Motor




#### ◇ Cable for Electromagnetic Brake




### ● Extension Cable

#### ◇ Extension Cable for Motor




#### ◇ Cable for Electromagnetic Brake




## Note on use of flexible extension cable

① Do not allow the cable to bend at the cable connector.




② For the bending radius, use at 6 times or more of the cable diameter.




③ The cable from the motor and the accessory cable are not for bending. If the motor cable is to be bent, bend it at the flexible cable.

#### • Flexible Connection Cable



#### • Flexible Extension Cable



# Driver Cable

## 1 General-Purpose Cable (RoHS)



This shielded cable has a half-pitch connector at one end of the cable for easy connecting to the driver.

### Note

- Note that as the length of the pulse signal line between the driver and controller increases, the maximum transmission frequency decreases.
- Install a connector that matches the controller you are using to the other end of the cable.


## Product Line

Product Name	Applicable	Length L (m)
<b>CC36D1-1</b>	<b>ARD-K</b>	1
<b>CC36D2-1</b>	For CN5 (36 pins)	2

## Dimension (Unit = mm)

### CC36D1-1, CC36D2-1

Conductor: AWG28 (0.08 mm<sup>2</sup>)



## 2 Connector - Terminal Block Conversion Unit (RoHS)



**CC36T1**

This is a conversion unit that connects a driver to a programmable controller using a terminal block.

- Includes a signal name plate for easy, one-glance identification of driver signal names
- DIN-rail installable
- Cable Length: 1 m


## Product Line

Product Name	Applicable	Length m
<b>CC36T1</b>	<b>ARD-K</b> For CN5 (36 pins)	1

## Dimension (Unit = mm)


### CC36T1

CAD B438



### Terminal Block Pin No.

[19]	[20]	[21]	[22]	[23]	[24]	[25]	[26]	[27]	[28]	[29]	[30]	[31]	[32]	[33]	[34]	[35]	[36]
[1]	[2]	[3]	[4]	[5]	[6]	[7]	[8]	[9]	[10]	[11]	[12]	[13]	[14]	[15]	[16]	[17]	[18]




### Applicable Crimp Terminal

- Terminal Screw Size: M3
- Tightening Torque: 1.2 N·m
- Minimum Applicable Lead Wire: AWG22 (0.3 mm<sup>2</sup>)

### Note

- Round terminals cannot be used.



# Battery Set (RoHS)

You need to connect a battery set to use a built-in controller driver as an absolute backup system.

## Product Line

Product Name	Applicable
<b>BATO1B</b>	<b>ARD-KD</b>



## Specifications

Item	Content
Battery Type	Sealed nickel-metal hydride rechargeable single cells
Nominal Voltage	2.4 V
Rated Capacity	1900 mAh
Expected Life	Approx. 4 years*1
Charge Time	32 hours*1
Data Retention Period	Approx. 360 hours (approx. 15 days)*1*2
Operating Ambient Temperature	0~+40°C (non-freezing)
Operating Ambient Humidity	45~85% (non-condensing)


\*1 At an ambient temperature of 20°C

\*2 After the power is cut OFF at full charge

## Dimensions (Unit = mm)

Mass: 0.1kg

CAD B560





# RS-485 Cable (RoHS)

This cable is used to connect built-in controller drivers with each other for multi-axis operation.

## Product Line

Product Name	Applicable	Length L (m)
<b>CC001-RS4</b>	<b>ARD-KD</b>	0.1
<b>CC002-RS4</b>		0.25

## Dimensions (Unit = mm)



# Network Converter (RoHS)

The network converter converts higher layer protocol to Oriental Motor's proprietary RS-485 protocol. It enables you to control Oriental Motor's RS-485 compatible products under higher layer protocol environment.

## Product Line

Network Type	Product Name
CC-Link-Compatible	<b>NETC01-CC</b>
MECHATROLINK-II Compatible	<b>NETC01-M2</b>
MECHATROLINK-III Compatible	<b>NETC01-M3</b>



Features	Lineup	System Configuration	Product Line	Specifications and Characteristics	Dimension	Connection and Operation	Combination List	Extended Functions	How to Read Specifications and Characteristics	Accessory	Controller
----------	--------	----------------------	--------------	------------------------------------	-----------	--------------------------	------------------	--------------------	--	-----------	------------

# Flexible Coupling

Features

Lineup

System Configuration

Product Line

Specifications and Characteristics

Dimension

Connection and Operation

Combination List

Extended Functions

How to Read Specifications and Characteristics

Accessory

Controller

A flexible coupling ideal for the **AR** Series is available. Once you have decided on a type and/or applications of motor/gear, you can select the recommended size of coupling easily. All motor shaft diameters of stepping motor packages are available (including geared motors).



MCV Coupling



MC Coupling



MCS Coupling

## Selecting a Coupling

Coupling Type	Motor Type	Standard	Application	
			TH Geared	PS Geared
<b>MCV</b> Coupling	○	—	High position accuracy and vibration suppression	
<b>MC</b> Coupling	○	—	High Positioning Accuracy	
<b>MCS</b> Coupling	○	○	High Strength and High Positioning Accuracy	

## MCV Coupling (RoHS)

This one-piece coupling is made by forming a rubber isolator in an aluminum alloy hub.



## Product Line

Product Name
<b>MCV15</b> □
<b>MCV19</b> □
<b>MCV25</b> □
<b>MCV30</b> □


● A number indicating the coupling inner diameter is entered where the box □ is located within the product name.

## Product Number Code

**MCV 30 10 14**

① ② ③ ④

- ① **MCV** Coupling
- ② Outer Diameter of Coupling
- ③ Inner Diameter d1 (Smaller side) (**06A** represents  $\phi 6.35$  mm.)
- ④ Inner Diameter d2 (Larger inner diameter)



● For inner diameter d1, the smaller of the motor shaft diameter or the driven shaft diameter is entered.  
For inner diameter d2, the larger of the motor shaft diameter or the driven shaft diameter is entered.

## Coupling Selection Table

Series			Coupling Type	Motor Shaft Diameter mm	Driven Shaft Diameter mm								
Type	Frame Size	Product Name			03	04	05	06	06A	08	10	12	14
Standard Type	28 mm	<b>AR24, AR26</b>	<b>MCV15</b>	05 $\phi 5$	●	●	●	●					
	42 mm	<b>AR46</b>	<b>MCV19</b>	06 $\phi 6$		●	●	●			●		
	60 mm	<b>AR66, AR69</b>	<b>MCV25</b>	10 $\phi 10$			●	●	●	●	●	●	
	85 mm	<b>AR98</b>	<b>MCV30</b>	14 $\phi 14$				●	●	●	●	●	●

# MC Coupling (RoHS)

This is a slit-type one-piece coupling.



Set Screw Type



Clamp Type

## Product Number Code

**MC 25 08 10 S**

① ② ③ ④ ⑤

①	<b>MC</b> Coupling
②	Outer Diameter of Coupling
③	Inner Diameter d1 (Smaller side) ( <b>06A</b> represents $\phi 6.35$ mm.)
④	Inner Diameter d2 (Larger inner diameter)
⑤	Connection Method <b>S</b> : Set Screw Type <b>C2</b> : Clamp Type

● For inner diameter d1, the smaller of the motor shaft diameter or the driven shaft diameter is entered.  
For inner diameter d2, the larger of the motor shaft diameter or the driven shaft diameter is entered.

## Product Line


### Set Screw Type

Product Name
<b>MC12□S</b>
<b>MC16□S</b>
<b>MC25□S</b>
<b>MC32□S</b>

### Clamp Type

Product Name
<b>MC12□C2</b>
<b>MC16□C2</b>
<b>MC25□C2</b>
<b>MC32□C2</b>

● A number indicating the coupling inner diameter is entered where the box □ is located within the product name.



## Coupling Selection Table

Type	Frame Size	Product Name	Coupling Type	Motor Shaft Diameter mm	Driven Shaft Diameter mm								
					Driven Shaft Diameter mm								
					04	05	06	06A	08	10	12	14	16
Standard Type	28 mm	<b>AR24, AR26</b>	<b>MC12</b>	<b>05</b> $\phi 5$	○	○	○						
	42 mm	<b>AR46</b>	<b>MC16</b>	<b>06</b> $\phi 6$	○	○	○		○				
	60 mm	<b>AR66</b>	<b>MC25</b>	<b>10</b> $\phi 10$		○	○	○	○	○	○		
		<b>AR69</b>	<b>MC32</b>	<b>10</b> $\phi 10$			○	○	○	○	○	○	
	85 mm	<b>AR98</b>	<b>MC32</b>	<b>14</b> $\phi 14$					○	○	○	○	○

○ Common for both the set screw type and clamp type

○ Only for the set screw type

Features

Lineup

System Configuration

Product Line

Specifications and Characteristics

Dimension

Connection and Operation

Combination List

Extended Functions

How to Read Specifications and Characteristics

Accessory Controller

# MCS Coupling (RoHS)

This three-piece coupling adopts an aluminum alloy hub and a resin spider.



## Product Line

Product Name
<b>MCS14□</b>
<b>MCS20□</b>
<b>MCS30□</b>
<b>MCS40□</b>
<b>MCS55□</b>
<b>MCS65□</b>

● A number indicating the coupling inner diameter is entered where the box □ is located within the product name.


## Product Number Code

**MCS 30 08 12**

(1) (2) (3) (4)

(1)	<b>MCS</b> Coupling
(2)	Outer Diameter of Coupling
(3)	Inner Diameter d1 (Smaller side) ( <b>F04</b> represents $\phi 6.35$ mm.)
(4)	Inner Diameter d2 (Larger side) ( <b>F04</b> represents $\phi 6.35$ mm.)

● For inner diameter d1, the smaller of the motor shaft diameter or the driven shaft diameter is entered.  
For inner diameter d2, the larger of the motor shaft diameter or the driven shaft diameter is entered.



## Coupling Selection Table

Dimension	Type	Frame Size	Product Name	Gear Ratio	Coupling Type	Motor Shaft Diameter mm	Driven Shaft Diameter mm												
							04	05	06	F04	08	10	12	14	15	16	18	20	22
TH Geared Type		28 mm	<b>AR24-T□</b>	7.2, 10 20, 30	<b>MCS14</b>	05 $\phi 5$	●	●	●										
		42 mm	<b>AR46-T□</b>	3.6, 7.2, 10 20, 30	<b>MCS20</b>	06 $\phi 6$		●	●	●	●	●	●	●	●	●	●	●	
		60 mm	<b>AR66-T□</b>	3.6, 7.2 10, 20, 30	<b>MCS30</b>	08 $\phi 8$			●	●	●	●	●	●	●	●	●	●	
		90 mm	<b>AR98-T□</b>	3.6, 7.2, 10 20, 30	<b>MCS40</b>	08 $\phi 8$				●	●	●	●	●	●	●	●	●	●
PS Geared Type		28 mm	<b>AR24-PS□</b>	5, 7.2, 10	<b>MCS20</b>	08 $\phi 8$		●	●	●	●	●							
		42 mm	<b>AR46-PS□</b>	5, 7.2, 10 25, 36, 50	<b>MCS30</b>	10 $\phi 10$			●	●	●	●	●	●	●	●	●	●	
		60 mm	<b>AR66-PS□</b>	5, 7.2 10, 25, 36, 50	<b>MCS40</b>	12 $\phi 12$				●	●	●	●	●	●	●	●	●	
		90 mm	<b>AR98-PS□</b>	5, 7.2, 10 25, 36, 50	<b>MCS55</b>	12 $\phi 12$					●	●	●	●	●	●	●	●	●
PN Geared Type		28 mm	<b>AR24-N□</b>	5, 7.2, 10	<b>MCS20</b>	08 $\phi 8$		●	●	●	●	●							
		42 mm	<b>AR46-N□</b>	5, 7.2, 10	<b>MCS30</b>	10 $\phi 10$			●	●	●	●	●	●	●	●	●	●	
		60 mm	<b>AR66-N□</b>	5, 7.2 10, 25, 36, 50	<b>MCS40</b>	12 $\phi 12$				●	●	●	●	●	●	●	●	●	
		90 mm	<b>AR98-N□</b>	5, 7.2, 10 25, 36, 50	<b>MCS55</b>	12 $\phi 12$					●	●	●	●	●	●	●	●	●
Harmonic Geared Type		30 mm	<b>AR24-H□</b>	50, 100	<b>MCS30</b>	08 $\phi 8$			●	●	●	●	●	●	●	●	●	●	
		42 mm	<b>AR46-H□</b>	50, 100	<b>MCS40</b>	10 $\phi 10$				●	●	●	●	●	●	●	●	●	
		60 mm	<b>AR66-H□</b>	50, 100	<b>MCS55</b>	12 $\phi 12$					●	●	●	●	●	●	●	●	
		90 mm	<b>AR98-H□</b>	50, 100	<b>MCS65</b>	18 $\phi 18$						●	●	●	●	●	●	●	

● A number indicating the gear ratio is entered where the box □ is located within the product name.

Features

Lineup

System Configuration

Product Line

Specifications and Characteristics

Connection and Operation

Combination List

Extended Functions

How to Read Specifications and Characteristics

Accessory

Controller

# Motor Installation Bracket (RoHS)

Installation brackets are convenient for installation and securing a stepping motor and geared type stepping motor.



## Product Line

### Standard Type

Material: Aluminum alloy

Product Name	Motor Frame Size	Applicable Product
<b>PAFOP</b>	42 mm	<b>AR46</b>
<b>PALOP</b>		
<b>PAL2P-5</b>	60 mm	<b>AR66</b> <b>AR69</b>
<b>PAL4P-5</b>	85 mm	<b>AR98</b>

- The installation bracket base is built with holes large enough to allow for adjustments of belt tension after a motor is installed.
- These installation brackets can be perfectly fitted to the pilot of the stepping motors (excluding **PALOP**).

**Note**

- Not available for geared type.

### TH Geared Type

Material: Aluminum alloy

Product Name	Motor Frame Size	Applicable Product
<b>SOLOB</b>	42 mm	<b>AR46</b>
<b>SOL2A</b>	60 mm	<b>AR66</b>
<b>SOL5B</b>	90 mm	<b>AR98</b>

- Use the screws provided to install the **SOL2A**.

Since screws are not included with **SOLOB**, and **SOL5B**, prepare appropriate screws separately.

### PS Geared Type, PN Geared Type

Material: SS400

Surface Treatment: Electroless nickel plating

Product Name	Motor Frame Size	Applicable Product
<b>PLA60G</b>	60 mm	<b>AR66</b>
<b>PLA90G</b>	90 mm	<b>AR98</b>

- The installation bracket base is built with holes large enough to allow for adjustments of belt tension after a motor is installed.
- Motor installation screws are included.

### Harmonic Geared Type

Material: SS400

Surface Treatment: Electroless nickel plating

Product Name	Motor Frame Size	Applicable Product
<b>PLA60H</b>	60 mm	<b>AR66</b>
<b>PLA90H</b>	90 mm	<b>AR98</b>

- The installation bracket base is built with holes large enough to allow for adjustments of belt tension after a motor is installed.
- Motor installation screws are included.

For details on accessories, refer to Oriental Motor General Catalogue 2011/2012 or the personal Web catalogue on our website.  
<http://www.orientalmotor.com.sg/>

# Controller (Sold separately)


## Stored-Data Type Controller

### PG1200 (RoHS)

## Features

All operations including data setting can easily be performed using the 4 touch pads on the panel. In addition, the number of signal lines is reduced to a minimum for easy operation and connection.

- Jerk Limiting Control Function Suppresses Motor Drive Vibration
- Sequential-Step Positioning Operation/External Signal Operation Possible
- Maximum Oscillation Frequency 200 kHz
- 1-Pulse Output/2-Pulse Output Mode Select Possible



Recessed Installation Model



DIN Rail Installation Model

## Product Line

### Sink Logic

Product Line	Product Name
DIN Rail Installation Model	<b>PG1200N-D</b>
Recessed Installation Model	<b>PG1200N-U</b>

### Source Logic

Product Line	Product Name
DIN Rail Installation Model	<b>PG1200P-D</b>
Recessed Installation Model	<b>PG1200P-U</b>

Features  
Lineup  
System Configuration  
Product Line

Specifications and Characteristics  
Dimension  
Connection and Operation

Combination List  
Extended Functions

How to Read Specifications and Characteristics

Accessory  
Controller



### Safety Precautions

- To ensure correct operation, carefully read the Operating Manual before using it.
- The products listed in this catalogue are for industrial use and for built-in component. Do not use for any other applications.

- The factories which manufacture the products listed in this catalogue have obtained Quality Management Systems ISO9001 and Environment Management Systems ISO14001.
- The content listed in this catalogue such as performance and specifications of the products are subject to change without notice for improvements.
- The price of all products listed in this catalogue does not include the consumption tax etc.
- For details of the products, please contact the nearest dealer, sales office or the following "Order Support Center" or "Customer Support Center".
- CC<sub>link</sub> is a registered trademark of CC-Link Partner Association.
- MECHATROLINK-II is a registered trademark of YASUKAWA ELECTRIC CORPORATION.
- Modbus is a registered trademark of Schneider Automation Inc..
- **Orientalmotor** **OXSTEP** and **C-FLEX** are registered trademark or trademark of Oriental Motor in Japan and other countries.

# Orientalmotor

## SINGAPORE ORIENTAL MOTOR PTE LTD

31 Kaki Bukit Road 3, #04-02/04  
Techlink, Singapore 417818  
TEL: +65-6745-7344 FAX: +65-6745-9405  
<http://www.orientalmotor.com.sg/>

## ORIENTAL MOTOR (THAILAND) CO., LTD.

900, 8th Floor Zone C, Tonson Tower, Ploenchit Road,  
Lumpini, Pathumwan, Bangkok 10330 Thailand  
TEL: +66-2-251-1871 FAX: +66-2-251-1872  
<http://www.orientalmotor.co.th/>

## ORIENTAL MOTOR (INDIA) PVT.LTD.

No.810, 8th Floor, Prestige Meridian-1 No.29,  
M.G.Road, Bangalore, 560001, India  
TEL: +91-80-41125586 FAX: +91-80-41125588  
<http://www.orientalmotor.co.in/>

## Customer Support Centre

TEL: For Singapore: 1800-8420280 (Toll Free)  
For Malaysia: 1800-806161 (Toll Free)  
For Thailand: 1800-888881 (Toll Free)  
For Other Countries: +65-6842-0280  
Mail to: [support@orientalmotor.com.sg](mailto:support@orientalmotor.com.sg)

For more information please contact:

## ORIENTAL MOTOR (MALAYSIA) SDN. BHD.

**Headquarters & Kuala Lumpur Office**  
A-13-1, North Point Offices, Mid Valley City,  
No.1 Medan Syed Putra Utara 59200  
Kuala Lumpur, Malaysia  
TEL: +60-3-22875778 FAX: +60-3-22875528

### Penang Office

TEL: +60-4-6423788 FAX: +60-4-6425788

### Johor Bahru Office

TEL: +60-7-3314257 FAX: +60-7-3314259  
<http://www.orientalmotor.com.my/>

## Japanese Customer Support Centre

TEL: +65-6745-3008  
Mail to: [j-support@orientalmotor.com.sg](mailto:j-support@orientalmotor.com.sg)